

BRAKE INSPECTION

MA01R-08

- 1. INSPECT BRAKE PEDAL AND PARKING BRAKE See pages BR-6 and BR-52 ()
- 2. INSPECT BRAKE LINE PIPES AND HOSES HINT:

 $\label{lem:check_helphalic} Check_helphalice_circumference $$ and_ength_flhelprake_hoses_using_hmirror_as_lequired. Turn the front_wheels_flully_right_or_eft_before_checking_the_front_brake.$

- (a) ☐ Check [all [brake [lines [and [hoses flor.]
 - •□ Damage
 - •□ Wear
 - □ Deformation
 - □ Cracks
 - Corrosion
 - •□ Leaks
 - •□ Bends
 - •□ Twists
- (b) Check[all[clamps[for[ightness[and[connections[for[]eakage.
- (c) Check that the thoses and the sare clear of sharp edges, moving parts and the exhaust system.
- (d) Check[that[the[tines[install[in[through]the center of the grommets.]
- 3. INSPECT FRONT AND REAR BRAKE PADS AND DISCS

(FRONT[PADS:[See[page[BR-30])]) (REAR[PADS:[See[page[BR-40]]])

(FRONT[DISCS: See page BR-35) (REAR[DISCS: See page BR-45)

- 4. INSPECT PARKING BRAKE LININGS AND DRUMS (See page BR-52)
- 5. INSPECT OR CHANGE BRAKE FLUID (See page BR-4)

Fluid: SAE J1703 or FMVSS No.116 DOT3