HOW[TO[PROCEED[WITH[TROUBLESHOOTING]

05I2X-01

HINT:

- Use this procedure to trouble shoot the key reminder warning system.
- The intelligent ester | Ishould | be used in teps | and | s.

1 | VEHICLE BROUGHT TO WORKSHOP

2 | CUSTOMER[PROBLEM[ANALYSIS[CHECK[AND[SYMPTOM[CHECK

3 | INSPECT COMMUNICATION FUNCTION OF LARGE-SCALE MULTIPLEX COMMUNICATION SYSTEM (BEAN)

- (a) Use the intelligent tester to be calculated by the communication of the communication of
 - (1) (ECU[unconnected, communication[ine[malfunctioning)] Without code outputs, proceed to A.
 - (2) (ECU[unconnected, communication[ine[malfunctioning)] With code outputs, proceed to B.

BO GO MULTIPLEX COMMUNICATION SECTION (See page 05-3162)

Α

- 4 | PROBLEM SYMPTOMS TABLE (See page 05-2529)

B ☐ > Go to step 6

Α

5 | OVERALL ANALYSIS AND TROUBLESHOOTING

- (a) ☐ DATA ☐ LIST/ACTIVE ☐ TEST ☐ See ☐ page ☐ 5-1☐ 01).
 - (1) Inspection with the intelligent tester II ECU DATA LIST).
 - (2) Inspection with the intelligent tester I (ACTIVE TEST).
- (b) Terminals of ECU see page 5-2531).
- (c) On-vehicle inspection (see page 05-2611).
- (d) Inspection see page 5-2613)

6 ADJUST, REPAIR OR REPLACE

_		2 13 1 10 11 10 0 11 10 0	1.2.1.2
7	CONFIRMATION TEST		
	\neg		
\sim			
END			
END			