LEXUS hand-held tester

N DLC3

F12704

## PRE-CHECK

## **USING LEXUS HAND-HELD TESTER**

- (a) Hook up the LEXUS hand-held tester to the DLC3.
- (b) Monitor the ECU data by following the prompts on the tester screen.

## HINT:

LEXUS hand-held tester has a "Snapshot" function which records the monitored data.

Please refer to the LEXUS hand-held tester operator's manual for further details.

LEXUS LS430 (RM792E)

DI8LR-01