HOW[TO[PROCEED[WITH[TROUBLESHOOTING]
The intelligent itester ill can ibe i used at steps is, is and 11.
1 VEHICLE BROUGHT TO WORKSHOP
2 CUSTOMER[PROBLEM[ANALYSIS[(SEE[PAGE[05-238)
3 PROBLEM SYMPTOM CONFIRMATION
SYMPTOM[DOES[NOT[OCCUR[[Go[to[step[4])
SYMPTOM[OCCURS[[Go[to[step[5])
4 SYMPTOM SIMULATION (SEE PAGE 01-34)
5 DTC[CHECK[AND[CLEAR[(SEE[PAGE[05-248)
NORMAL SYSTEM CODE (Go to step 6)
TROUBLE CODE (Go to step 7)
6 PROBLEM SYMPTOMS TABLE (SEE PAGE 05-241)
7 DTC[CHART[(SEE[PAGE[05-254)
8 CIRCUIT INSPECTION (SEE PAGE 05-257 to 05-340)
9 IDENTIFICATION OF PROBLEM

DIAGNOSTICS - AIR SUSPENSION SYSTEM

10	REPAIR
11	CONFIRMATION TEST
END	