DISPS_01


DTC	B1248	AVC-LAN communication impossible	
-----	-------	----------------------------------	--

CIRCUIT DESCRIPTION

This DTC is output when communication stops between the gateway ECU and the AVC-LAN circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1248	Communication error between gateway ECU and AVC-LAN.	Gateway ECU
		Wire harness

WIRING DIAGRAM



INSPECTION PROCEDURE

1[]

Check[] Service[check[mode"[of[AVC-LAN]diagnosis[system.

CHECK:

Connection of the other connec

(w/o[LEXUS[havigation[system:[]Service[check[mode]]of[audio[system)(See[page[DI-1551)]

(w/[LEXUS[havigation[system:]]Service[check[mode"[bf]]LEXUS[havigation[system)(See[page[DI-1500)]

OK:

Radio display or Multi display: G/W: OK (System is normal)

G/W: EXCH (Replace gateway ECU) others: Troubleshoot for each diagnosis.

EXCH

Replace gateway ECU (See page N-35).

Other

Troubleshoot for each diagnosis.

OK

2

Check wire harness.

PREPARATION:

Pull out the ECU connectors mentioned below.

	Wire harness side connector of ECU	Terminal
G	Sateway FCU – Radio and player	GTX+ (G1-9) - TXS+ (R5-3) GTX- (G1-20) - TXS- (R5-6)

CHECK:

Check continuity of the wire harness between the connectors.

OK:

Continuity

NG

Repair or replace wire harness.

OK

Replace gateway ECU (See page N-35).