054G1-03

## HOW[TO[PROCEED[WITH[TROUBLESHOOTING]

L	11	N	ΙП	г

- Use[jhis[procedure[jo[]roubleshoot[]he[]defogger[]system.
- The intelligent tester is should be used in \$tep 3.
  - 1 | VEHICLE[BROUGHT[TO[WORKSHOP
  - 2 CUSTOMER[PROBLEM[ANALYSIS[CHECK[AND[\$YMPTOM[CHECK (See[page[05-2125)
  - 3 | CHECK[COMMUNICATION[FUNCTION[OF]LARGE-SCALE]MULTIPLEX[COMMUNICATION[SYSTEM[BEAN]
- (a) Use the intelligent tester to be calculated by the communication of the communication of
  - (1) (ECU[unconnected, communication[ine]malfunctioning)[Without]code[outputs, proceed[to]A.
  - (2) (ECU[unconnected, communication[ine]malfunctioning) [With code outputs, proceed to B.
    - B
      | Go[to[MULTIPLEX[COMMUNICATION[SECTION (See[page[05-3162)])]]

Α

- 4 | | PROBLEM[\$YMPTOMS[TABLE[[See[page]]
- (a) If the fault is not listed on the problem symptoms table, proceed to A.
- (b) If the fault is tisted on the problem symptoms table, proceed to B.

Α

- 5 OVERALL ANALYSIS AND TROUBLESHOOTING
- (a) ☐ Data ☐ Da
  - Inspection with the intelligent tester II (ACTIVE TEST).
- (b) Terminals of ECU see page 5-2127).
- (c) Inspection [see page 70-26).
  - 6 ADJUST, REPAIR OR REPLACE

7 CONFIRMATION TEST

END