## **PROBLEM SYMPTOMS TABLE**

720R3-01

Symptom	Suspected Area	See Page
All front seat heaters do not warm up	1. P-IG1 relay	72–33
	2. P-IG fuse	72–33
	3. Front seat heater switch	72-33
	4. Wire harness	72–33
Front LH seat cushion heater does not warm up	1. D S/HTR fuse	72–33
	2. D-IG1 relay	72–33
	3. Front seat heater switch	72–33
	4. Wire harness	72-33
	5. Front seat cushion heater LH	*
Front LH seatback heater does not warm up	1. D S/HTR fuse	72–33
	2. D-IG1 relay	72-33
	3. Front seat heater switch	72–33
	4. Wire harness	72–33
	5. Front seat cushion heater LH	*
	6. Front seatback heater LH	*
Front RH seat cushion heater does not warm up	1. P S/HTR fuse	72-33
	Front seat heater switch	72-33
	3. Wire harness	72-33
	Front seat cushion heater RH	*
	1. P S/HTR fuse	72–33
5 . 50	2. Front seat heater switch	72–33
Front RH seatback heater does not warm up	3. Wire harness	72–33 *
	4. Front seat cushion heater RH	*
	5. Front seatback heater RH	
All rear seat heaters do not warm up	1. RR S/HTR fuse	72–33
	2. L-IG1 relay	72–33
	3. Rear seat heater switch	72–33
	4. Luggagr room J/B ECU	72–33
	5. Wire harness	72–33
Rear LH seat cushion heater does not warm up	Rear seat heater switch	72–33
	2. Wire harness	72–33
	3. Rear seat cushion heater LH	*
Rear LH seatback heater does not warm up	Rear seat heater switch	72–33
	2. Wire harness	72-33
	3. Rear seat cushion heater LH	*
	4. Rear seatback heater LH	*
Rear RH seat cushion heater does not warm up	Rear seat heater switch	72–33
	2. Wire harness	72–33
	3. Rear seat cushion heater RH	*
Rear RH seatback heater does not warm up	Rear seat heater switch	72-33
	2. Wire harness	72–33
	3. Rear seat cushion heater RH	*
	4. Rear seatback heater RH	*
Temperature of front seat heater cannot be adjusted (seat does not warm up)	Front seat heater switch	72–33
	2. Wire harness	72–33
• • • • • • • • • • • • • • • • • • • •	Rear seat heater switch	
Temperature of rear seat heater cannot be adjusted (seat does not warm up)		72–33 72–33
(Joar 4000 Hor warm up)	2. Wire harness	12-33

## NOTICE:

\* The seat heater can only be inspected through other items is ted in the suspected area of the problem symptoms able (see page 72-31). If hormal operations of these items are confirmed, the seat heater may be malfunctioning.

## HINT:

The seat heater system is part of the large-scale multiplex communication system. This system features shared communication wiring that reduces the wiring complexity of the communication lines. The first step in any repair is to confirm the proper operation of the communication system. Proceed with troubleshooting after the communication has been verified (see the multiplex communication system).