CRUISE CONTROL SYSTEM PRECAUTION

05H05-01

NOTICE:

When the negative (-) battery terminal is disconnected, initialize the following systems after the terminal is reconnected.

System Name	See page
Power Window Control System	01–20
Front Power Seat Control System	01–20
Back Guide Monitor System	01–20

- 1. Pay attention to the following points when inspecting the cruise control system.
- (a) Push the cruise control main switch ON-OFF button off when not using the cruise control.
- (b) Be careful of vehicle speed increase when driving downhill with the cruise control on.
- (c) RESUME/ACCEL operation, after canceling the cruise control, works as RESUME, and works as ACCEL while the cruise control system is in operation.
- (d) Push the cruise control main switch ON-OFF button off and reset the cruise control if the CRUISE main indicator light blinks while the cruise control system is in operation. When the cruise control cannot be set by this procedure or cancelled immediately after setting, there may be a malfunction in the system.
- (e) Do not use the cruise control system where the road conditions are as follows:
 - Heavy traffic
 - Steep downhill
 - Sharp turns
 - Icy or snowy roads
 - Slippery roads