KNOCK SENSOR
COMPONENTS

100LJ–01

PS Air Hose

Intake Air Connector

Ventilation Hose

5.0 (51, 44 in.·lbf)

V–Bank Cover

Air Cleaner Inlet No. 1

A93844

5.0 (51, 44 in.·lbf)

7.5 (77, 66 in lbf)

Heater Pipe

Engine Wire Protector

5.0 (51, 44 in.·lbf)

VSV Connector
for IAC Valve

Engine Wire Clamp

Noise Filter
Connector

PS Air Hose

Brake Booster Hose

Engine Wire

Throttle Body

Injector Connector

18 (185, 13)

18 (185, 13)

Fuel Pipe Sub–assy No. 2

VSV Connector for
EVAP

◆ Gasket

◆ Gasket

EVAP Hose

★ 35 (360, 26)

Fuel Main Tube

Knock Sensor (Bank 1)

20 (204, 15)

20 (204, 15)

Knock Sensor (Bank 2)

N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non–reusable part

★ For use with SST

Y

A94369