RADIATOR ASSY ON-VEHICLE CLEANING

100011 01



(a) Check that the radiator and condenser are not blocked with leaves, dirt, or insects,. Clean the hose connection.If the fins are clogged, wash them with water or a steam cleaner and dry with compressed air.

NOTICE:

 If the distance between the steam cleaner and the core is too close, the fins may become damaged.
 Keep the following injection distance.
 Standard:

Injection Distance	Injection Pressure
300 mm (11.811 in.)	2,942 to 4,903 kPa (30 to 50 kgf·cm², 427 to 711 psi)
500 mm (19.685 in.)	4,903 to 7,845 kPa (50 to 80 kgf·cm², 711 to 1,138 psi)

- If the fins are bent, straighten them with a screwdriver or pliers.
- Never apply water directly onto the electronic components.

