B78382

05I5N-01

LOCATION For RHD vehicle, look at the same location on the opposite side of the vehicle Theft Warning ECU Passenger Side J/B Gateway ECU Driver Side J/B MPX-B3 Fuse Driver Side J/B ECU MPX-IG Fuse AM1 Fuse 0000 Luggage Door Opener Switch Luggage Door Closer Assy Luggage Door Courtesy Switch FL Block Assy Luggage Door Closer Motor D/C CUT Fuse Position Detection Switch Luggage Electrical Key Switch* (Push Switch) Luggage Room J/B Assy ● Luggage Room J/B ECU Luggage Compartment Door Key Unlock Switch Luggage Compartment Door Striker Assy

■ Luggage Door Open Switch

*: w/ Smart Key System