DI8TY-01

31. [Turning [Light [Control switch to] TAIL does not light up panel switches.

INSPECTION PROCEDURE

1 Display check mode. (TAIL signal)

NG[

Replace[multi[display[See[page[N-35]].

OK

Replace[and[repair]wire[harness[See[page IN-35]].