DI73S-02

DTC P1566/54 Inputsignal circuit abnormal

CIRCUIT DESCRIPTION

SeepageDI-864.

DTC[No.	Detection <u></u> tem	Trouble[<u>A</u> rea
P1566/54	Stop[light[switch[]nput[signal[abnormal. Cruise[control[switch[]nput[signal[abnormal.	•Engine[and[ECT[ECU

INSPECTION PROCEDURE

Checkandreplace Engine and ECT ECU (See page 1N-35).