DI7P4-04

11 No sound radio, cassette tape, CD) can be heard from driver side door speaker only.

INSPECTION PROCEDURE

1 | Service check mode (See page DI-1500).

NG

Troubleshoot for each diagnosis.

OK

2 | Chec

Check[wire[harness[between[havigation[ECU[and[stereo[component[amplifier.

PREPARATION:

Disconnect[]he[]havigation[]ECU[]and[]stereo[]component[]amplifier[]connectors.

CHECK:

- (a) Checkcontinuity of the wire harness between terminal AUI+ of the havigation ECU and terminal FL+ of the stereo component amplifier.
- (b) Check continuity of the wire harness between terminal AUI of the havigation ECU and terminal FL of the stereo component amplifier.

OK:

Continuity

NG

Replace or repair wire harness or connector (See page N-35).

ΟK

3 Check navigation system voice.

OK∐

Replace[stereo@component@amplifier[See_page IN-35).

NG

4[]

Check stereo component amplifier.

CHECK:

Check the voltage of terminal N-MU.

<u>OK:</u>

N-MU:[\$ee[]*Stereo[component[amplifier"]of[]*TERMINAL[OF[ECU"

NG

Go[to[step[7.

OK

5∏

Check wire harness between navigation ECU and driver side door speaker.

PREPARATION:

Disconnect he havigation ECU and driver side door speaker connectors.

CHECK:

- (a) Check continuity of the wire harness between terminal AUO+ of the havigation ECU and terminal of the driver side door speaker.
- (b) Check continuity of the wire harness between terminal AUO of the havigation ECU and terminal of the driver side door speaker.

OK:

Continuity

NG

Replace or repair wire harness or connector (See page N-35).

OK

6∏

Check driver side door speaker.

PREPARATION:

Disconnect[]he[driver[\$ide[door[\$peaker[connectors.

CHECK:

Check[]he[]resistance[]between[]erminals 1[]and[]2.

OK:

Resistance: 2 - 9 1



Replace driver side door speaker.

OK

Replace havigation ECU (See page N-35).

7[]

Check the navigation ECU.

CHECK:

Check[voltage[terminal[MUTE.

OK:

MUTE: [See] Navigation [ECU" [of] TERMINAL [OF [ECU".

NG□

Replace[or[repair[wire[harness[or[connector (See[page[N-35).

OK

Replace[the[navigation[ECU[See[page IN-35]]]]