AVC-LAN CIRCUIT (RADIO RECEIVER ASSY - GATEWAY ECU)


CIRCUIT DESCRIPTION

Each unit of the radio receiver assy system connected to AVC-LAN (communication bus) communicates by transferring the signals from each switch.

When +B short and GND short occur in this AVC-LAN, radio receiver assy system will not function normally as communication is discontinued.


In AVC-LAN, radio receiver assy becomes the communication master, and the radio receiver assy has enough resistance necessary for transmitting the communication.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT| RADIO| RECEIVER ASSY



(a) Measure[the[resistance[according[to[the[value(s)]]n[the table[below.

Standard:


Tester@onnection	Condition	Specified@ondition
TX+ -[]TX-	Always	60∏o[\$0[Ω

NG

REPLACE[RADIO[RECEIVER[ASSY (SEE[PAGE[67-5)




2 | CHECK[HARNESS[AND]CONNECTOR(RADIO]RECEIVER[ASSY - [GATEWAY[ECU)]



- (a) Disconnect[the@onnector[from[the@adio@eceiver@ssy[R4 and@ateway[ECU[G1.
- (b) Measure the resistance according to the value (s) in the table below.

Standard:

Tester[connection	Condition	Specified@ondition
TX+ -[GTX+	Always	Below[] [Ω
TX GTX-	Always	Below[] [Ω
TX+ -[Body[ground	Always	10[k͡᠒[þr[ḫigher
TX Body[ground	Always	10[k͡k͡k͡k͡kɪ͡bigher



NG | REPAIR | OR | REPLACE | HARNESS | OR CONNECTOR

OK

PROCEED[TO[NEXT[CIRCUIT]]NSPECTION[\$HOWN]]N[DIAGNOSTIC[TROUBLE[CODE]CHART (SEE[PAGE[05-1673)