05B0F-06

DTC B2793 TRANSPONDER CHIP MALFUNCTION

CIRCUIT DESCRIPTION

This DTC is output when: 1) iduring the ikey code itegistration, a key malfunction occurs; or 2) the ikey code was unable to be itegistered properly. Follow the inspection procedure below.

DTC[No.	DTC[Detection[Condition	Trouble[Area
B2793	Transponder@hip@nalfunction	Key

INSPECTION PROCEDURE

- 1 RE-REGISTER KEY
- (a) Delete [] D
- (b) Re-register the key, and check that the engine starts with the key.

OK: Engine starts.

NG>	REPLACE KEY

OK

NORMAL (INSPECTION FINISHED)