05840-08

HOW TO PROCEED WITH TROUBLESHOOTING



- Use this procedure to trouble shoot the seat belt warning system.
- •□ The intelligent itester is should be used in teps in the intelligent itester.
 - 1 | VEHICLE[BROUGHT[TO[WORKSHOP
 - 2 CUSTOMER[PROBLEM[ANALYSIS[CHECK[AND[SYMPTOM[CHECK[See[page 05-1328]
 - 3 INSPECT COMMUNICATION FUNCTION OF LARGE-SCALE MULTIPLEX COMMUNICATION SYSTEM (BEAN)
- (a) Use the intelligent tester to check for hormal function of the imultiplex communication system.
 - (1) (ECU[unconnected, communication[ine[malfunctioning)] Without code outputs, proceed to A.
 - (2) (ECU[unconnected, communication[ine]malfunctioning) [With code outputs, proceed to B.
 - B
 | Go
 | To
 | MULTIPLEX
 | COMMUNICATION
 | SYSTEM (See page 05-3128)

Α

- 4 | PROBLEM[\$YMPTOMS[TABLE[[See[page[05-1329]
- (a) If the fault is not isted on the problem symptoms table, proceed to A.
- (b) If the fault is tisted on the problem symptoms table, proceed to B.

Α

- 5 OVERALL ANALYSIS AND TROUBLESHOOTING
- (a) DATAILIST/ACTIVE TEST (see page 05-1833)
 - (1) Inspection with the intelligent tester II (DATA LIST)
- (b) Terminals of ECU (see page 05-1330)
- (c) Inspection (see page 61-5)
 - 6 ADJUSTMENT, REPAIR OR REPLACE

7	CONFIRMATION TEST
END	