DTC	P0500	VEHICLE SPEED SENSOR CIRCUIT MALFUNCTION
DTC	P0503	VEHICLE[\$PEED[\$ENSOR[CIRCUIT MALFUNCTION

CIRCUIT[DESCRIPTION

See page 05-172.

DTC[No.	DTC[Detection[Condition	Trouble[A rea
P0500	This@rouble@ode@s@utput@vhen@he@ehicle@speed@signal@rom the@vehicle@speed@sensor@s@ut@or@.14@sec.@r@nore@vhile@he cruise@ontrol@s@n@peration.	
P0503	Momentary[interruption[and[inoise[are[detected[when[ac]apid change[of[yehicle[speed[occurs[while[the[cruise[control[is]in operation.	

WIRING DIAGRAM

See page 05-172.

INSPECTION PROCEDURE

See page 05-172.