## **SEAT HEATER SYSTEM**

**LOCATION** 

FL Block Assy ● P-J/B H-fuse ● LUG J/B H-fuse ● ALT H-fuse ● D-J/B H-fuse Passenger Side J/B ● P S/HTR Fuse Front Seat Heater Switch ● P-IG Fuse ● P-IG1 Relay Driver Side J/B ● D-IG1 Relay D S/HTR Fuse AM1 Fuse Front Seatback Heater LH Front Seat Cushion Heater RH Front Seat Cushion Front Seatback Heater LH Heater RH Rear Seat Heater Switch Rear Seat Cushion Rear Seatback Heater RH Heater LH Luggage Room J/B Assy ● RR S/HTR Fuse Rear Seat Cushion Rear Seatback ● L-IG1 Fuse Heater RH Heater LH Luggage Room J/B ECU B77450