## BACK[GUIDE[MONITOR[SYSTEM PRECAUTION

OEHOH OF

## NOTICE:

When disconnecting the megative (-) (battery terminal, initialize the following systems after the terminal is reconnected.

System[Name	See[page
Power[Window[Control[System	01- <b>2</b> 0
Front[Power[Seat[Control[System	01-20
Back[Guide[Monitor[System	01-20

## 1. | POINTS|TO|NOTICE|WHEN|SERVICING

- (a) The maximum steering angle setting must be carried out with the engine on. Apply the parking brake, depress the brake pedal, move the shift ever to the position, and ensure that the vehicle is not funning.
- (b) Pay attention for the following points when servicing:
  - (1) When disconnecting the battery cable, SYSTEM NITIALIZING appears on the screen. In this case, correct he steering angle heutral point see page 5-1913).
  - (2) When replacing the relevision camera ECU, SYSTEM NOT READY appears on the screen. In this case, set he maximum steering angle and steering angle heutral point, and adjust the line display position. In addition, when the relevision camera assy is replaced or display position is required see page 5-1914).