Combination Meter * 1 : w/ LEXUS Navigation System * 2 : w/o LEXUS Navigation System L12B, L13C LUGGAGE ROOM J/B ECU 6 D 2 A, D 3 B D 4 C

DRIVER SIDE J/B ECU F19 FUEL SENDER (Main) FUEL SENDER (Sub)

28 LS 430 (RHD) (Cont' d)

(Cont. next page)

* 3 : CHECK ENGINE(Europe)

* 4 : Europe * 5 : Australia

LH side of cylinder head