① : Engine Room No.1 R/B

: Engine Room No.1 J/B

Engine Compartment Left (See Page 76)

*1 : H-LP R LWR *2 : H-LP L LWR

