CIRCUIT DESCRIPTION

This DTC is output when: 1) during the key code itegistration, a key malfunction occurs; or 2) the key code was unable to be registered properly. Follow the inspection of procedure below.

| | DTC[No. | DTC[Detection[Condition | Trouble [Area |
|---|---------|-----------------------------|-----------------------|
| I | B2793 | Transponder@hip@malfunction | Smart[key |

INSPECTION PROCEDURE

- 1 RE-REGISTER KEY
- (a) Delete the DTC see page 05-3006.
- (b) Re-register the key, and check that the engine starts with the key.

OK: Engine starts.

| NG> | REPLACE KEY |
|-----|-------------|

OK

NORMAL (INSPECTION FINISHED)