
ABS[WITH[EBD]&[BA[&[TRC]&[VSC[\$YSTEM[AND] PROGRESSIVE[POWER[\$TEERING]

DI1GR-06

HOW TO PROCEED WITH TROUBLESHOOTING Troubleshooting in accordance with the procedure on the following pages.



Fail[safe]function:

ABS[WITH[EBD[&[BA[&[TRC[&[VSC[\$YSTEM:

When a flailure occurs in the ABS & BA&TRC & VSC by stems, the ABS warning ight and VSC of Findicator light are it and the ABS & BA&TRC & VSC operations are prohibited. In addition to this, when the flailure that disables the BD operation occurs, the brake warning ight is it as well and the BD operation is prohibited. PROGRESSIVE POWER STEERING:

When the circuit PPS solenoid circuit staulty, efficiency of the power-assisted operation solenoid in steering operation becomes constantly heavy.