05I4K-01

## HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

- Use[jhis[procedure[jo]troubleshoot[jhe[power[shoulder[belt[anchorage[system.
- The intelligent ester is should be used in teps and .
  - 1 | VEHICLE BROUGHT TO WORKSHOP
  - 2 | CUSTOMER[PROBLEM[ANALYSIS[CHECK[AND[SYMPTOM[CHECK
  - 3 INSPECT COMMUNICATION FUNCTION OF LARGE-SCALE MULTIPLEX COMMUNICATION SYSTEM (BEAN)
- (a) Use the intelligent tester in the light of the ck for in ormal function of the inultiplex communication system.
  - (1) (ECU[unconnected, communication[ine[malfunctioning)] Without code outputs, proceed to A.
  - (2) (ECU[unconnected, communication[ine[malfunctioning)] With code outputs, proceed to B.
    - B Go to MULTIPLEX COMMUNICATION SECTION (See page 05-3162)

Α

- 4 | PROBLEM[\$YMPTOMS[TABLE[(See[page[05-1289)
- (a) If the fault is not listed on the problem symptoms table, proceed to A.
- (b) If the fault is listed on the problem symptoms table, proceed to B.

B Go to step 6

Α

- 5 OVERALL ANALYSIS AND TROUBLESHOOTING
- (a) ☐ DATA ☐ LIST/ACTIVE ☐ TEST ☐ See ☐ page ☐ 5-1☐ 01).
  - (1) Inspection with the intelligent tester II (ECU DATA LIST).
  - (2) Inspection with the intelligent tester II (ACTIVE TEST).
- (b) Terminals of ECU see page 5-1290).
- (c) ☐ On-vehicle[inspection[[see][page][05-1]317] ☐
- (d) Inspection see page 5-1319)
  - 6 ADJUST, REPAIR OR REPLACE

7	CONFIRMATION TEST
END	