REAR RIGHT SEAT CONTROL SYSTEM HOW TO PROCEED WITH TROUBLESHOOTING

DI8L1-01

HINT:

The ECU of this system is connected to the multiplex communication system. Therefore, before starting troubleshooting, make sure to check that there is no trouble in the multiplex communication system.

