POWER[TILT[AND[POWER]TELESCOPIC[STEERING COLUMN

PRECAUTION

UEIUO U

NOTICE:

When the inegative (-) battery terminal is disconnected, initialize the following systems after the terminal is reconnected.

System Name	See page
Power Window Control System	01- 2 0
Front Power Seat Control System	01- 2 0
Back Guide Monitor System	01-20