DI8MK-01

PROBLEM[\$YMPTOMS[TABLE

Symptom	Suspect[Area	See[page
*Problem symptom table on front control system does not operate. (All)	Power source circuit Ignition switch power source circuit Front light ECU	DI-11 <u>6</u> 7 DI-11 <u>6</u> 9 IN-35
Horn does not sound.	Horn circuit Front light ECU	DI-11 <u>8</u> 0 IN-35

^{*:} Front light control systems: Headlights, clearance lights, front fog lights, horn, washer system and washer fluid level warning.