
SMART KEY CANCEL SWITCH CIRCUIT

CIRCUIT DESCRIPTION

The smart key cancel switch is located on the lower part of the instrument panel. Pressing this switch stops all smart key functions.

If the smart key functions cannot be canceled by pressing the cancel switch or the entire smart system does not operate when the cancel switch is off, this circuit may be malfunctioning.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 | READ[VALUE[OF[INTELLIGENT[TESTER[I

- (a) Connect the intelligent tester to the CDLC3.
- (b) Turn the ignition switch ON and press the intelligent tester I main switch ON.
- $(c) \label{lem:lems_below_in_like_DATA_LIST_and_read_like_displays_on_like_intelligent_lester_ll.} \\$

Theft[warning[ECU:

Item	Measurement[]tem/ Display[[Range)	Normal Condition	Diagnostic[N ote
Smart[key[\$witch	Smart[key[switch[signal/ ON[or[OFF	ON:[Smart[key[cancel[switch[s]spressed]]smart[key[cancel[switch[s]spressed]]switch[spressed]]switch[spressed]	-


OK: OFF" (smart[key[cancel]switch[is[not[pressed)]appears[on[the[screen.

NG Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-2634)

2 INSPECT SMART KEY CANCEL SWITCH ASSY



- (a) Remove the smart key cancel switch assy.
- (b) Measure the switch resistance.

Standard:

Tester Connection	Condition	Specified Condition
1 – 2	Switch pushed	10 or $k\Omega$ higher
1 – 2	Switch not pushed	Below 1 Ω

NG

REPLACE SMART KEY CANCEL SWITCH

OK

3 CHECK WIRE HARNESS (SMART KEY CANCEL SWITCH ASSY – THEFT WARN-ING ECU AND BODY GROUND)

Wire Harness Side T5 Theft Warning ECU CNSL 1 2 3 4 5 6 7 8 9 1011121314151617181920 2122232425202720293031323334353037383940 S15 Smart Key Cancel Switch

- (a) Disconnect the T5 ECU connector.
- (b) Disconnect the S15 switch connector.
- (c) Measure the resistance of between the wire harness side connector.

Standard:

Tester Connection	Specified Condition	
S15-2 - T5-10 (CNSL)	Below 1 Ω	
S15-1 - Body ground	Below 1 Ω	

NG

B80303

REPAIR OR REPLACE HARNESS AND CONNECTOR

ок

REPLACE THEFT WARNING ECU