LOCATION

05HY1–01

▶Smart Key◀

Master Key

Mechanical Key

Sub Key

Mechanical Key

Flat Key

Key Plate

Electronic Key

Smart Indicator Light

Combination Meter
● Meter ECU
● Buzzer

Inside Rear View Mirror
● Wireless Door Lock Receiver

Driver Door ECU

Room Oscillator
(Front)

Door Oscillator
Front LH

Smart Key Cancel Switch

Y

B74254

Steering Lock ECU

Theft Warning ECU

Ignition Switch

Engine Switch
● Key Unlock Warning Switch
● Push Switch

Outside Handle
● Touch Sensor and Antenna
● Lock Switch

▶Outside Handle◀

Touch Sensor and Antenna

Lock Switch

Door Oscillator Front RH

Rear Door RH ECU

Outside Handle
● Touch Sensor and Antenna
● Lock Switch

Door Oscillator Rear RH

Passenger Door ECU

Rear Door LH ECU

Door Oscillator
Rear LH

Smart Trunk
Open Switch

Outside Handle
● Touch Sensor and Antenna
● Lock Switch

Luggage Room Receiver

Room Oscillator

Luggage Room
J/B ECU

Trunk Oscillator
(Inner)

Antenna

Trunk Oscillator
(Outer)

Y

B74255