

## 12 LS 430 (LHD) (Cont' d) SRS S30 SIDE AIRBAG SENSOR REAR LH S28 SIDE AIRBAG SENSOR FRONT LH J17(A), J18(B) JUNCTION CONNECTOR A26 (A), A27 (B), A28 (C) AIRBAG SENSOR ASSEMBLY SRS WARNING LIGHT [COMB. METER] VUPR SSR+ SSR- ESR ICL+ ICL-ICR+ ICR-S31 SIDE AIRBAG SENSOR REAR RH S29 SIDE AIRBAG SENSOR FRONT RH C18 CURTAIN SHIELD AIRBAG SQUIB LH C19 CURTAIN SHIELD AIRBAG SQUIB RH Right side of II Right side of IH

LS 430 (EWD435F)

1055