

NetSecure Router - Administrator Guide

Default Credentials

Username: admin | Password: admin123. Change credentials immediately after first login.

Port Forwarding

Navigate to Settings > Advanced > Port Forwarding to configure ports for gaming or remote access.

Firmware Update

Download the latest firmware from the official NetSecure portal before updating.

Troubleshooting

If internet access fails, reboot the router and verify WAN configuration.

Component	Status
Power Module	Operational
Connectivity	Stable
Firmware	Updated