

Inspection schedule

The main hydraulic pump must be inspected every 200 operating hours. The inspection covers the housing, the bearings and the drive coupling. Record the hour meter reading in the logbook after each inspection. If the pump runs continuously, the inspection falls due roughly every eight days.

Seal replacement

Mechanical seals are replaced once a year, or sooner if leakage exceeds ten drops per minute. Shut down and isolate the pump before opening the seal chamber. Use only seals from the approved parts list, and note the batch number in the maintenance record.

Emergency shutdown

In an emergency press the red stop button on the control cabinet. The pump stops within three seconds and the inlet valve closes automatically. After a shutdown, the shift supervisor must be informed before the pump is restarted. A restart requires a second person to confirm the pipe pressure is below two bar.

Lubrication

Bearings are lubricated every 500 operating hours with lithium grease of grade NLGI 2. Apply two pumps of the grease gun per bearing. Over-greasing raises the bearing temperature and should be avoided.

Vibration limits

Vibration is measured monthly at the bearing housing. A reading above 7.1 millimetres per second means the pump has to be taken out of service. Readings between 4.5 and 7.1 are marked as a warning and measured again after one week.

Spare parts

A spare impeller and two sets of seals are kept in the storage cabinet in room B2. The key is held by the shift supervisor. When a spare is used, it has to be reordered within five working days.