## **Operating Instruction for OTDR FHO5000-S20**

Firstly, install the PC software.



Double-click setup. exe, follow the prompts to install.



After successful installation, double-click

on the desktop to start the PC software.

The main interface is shown below:




Figure 1-1

Secondly, the instruction to use PC software.

1. Select the menu "File" -> "Open File" to browse curve data that needs to be opened. It's shown in Figure 2-1 and Figure 2-2




Figure 2-1




Figure 2-2

Open the .sor file. It's shown in Figure 2-3




Figure 2-3

2. After opening curve, select the menu "File" -> "Print Preview" or "Print", you can print preview or the curve directly. It's shown in Figure 2-4




Figure 2-4

3. Select the menu "Tool" -> "Remote Connect", OTDR instrument will be synchronized with the PC software for remote operation. It's shown in Figure 2-5 and Figure 2-6




Figure 2-5




Figure 2-6

4. Select the menu "Tool" -> "Remote Setting" for remote control settings. It's shown in Figure 2-7 and Figure 2-8




Figure 2-7




Figure 2-8

5. Select the menu "View" -> "Wave Screen Setting". The curve can be set up, such as the choice of colors and other attributes. It's shown in Figure 2-9 and Figure 2-10




Figure 2-9




Figure 2-10

6. Select the menu "Report" -> "Report Wizard" , you can export Excel file format of the curve data, the operation is shown in Figure 2-11 to Figure 2-19




Figure 2-11




Figure 2-12




Figure 2-13




Figure 2-14




Figure 2-15




Figure **2-16** 




Figure 2-17




Figure 2-18




Figure 2-19

Thirdly, uninstall the software.

Select "Start" -> "All Programs" -> "FHO5000" -> "Uninstall.exe", click "Uninstall.exe" to uninstall the software.