

Loading Routes via the USB Port

This is a very simple process but some attention must be given to a couple of important facts.

- 1) The name of the message file must always be: message1.txt
- 2) Any word processor can be used to edit the file but it is very important that the file is saved as a PLAIN TEXT FILE.
- 3) The route file must be the only file on the USB stick.
- 4) There must always be a four-digit numeric route number. 0001 to 9999
- 5) The route numbers do not have to follow on from each other but must be listed from lowest to highest number. Only normal keyboard characters can be used.
- 6) Whether the route name is typed in upper or lower case characters the sign will always default to upper case.
- 7) The route name could be a maximum of 32 characters, however we recommend that not more than 16 characters be used, as it takes too long to scroll past.
- 8) There must be one space between the ROUTE NUMBER and ROUTE NAME.
- 8) Once all the routes are listed in the message1.txt file, make sure the Destination is switched off. Plug the USB stick into the bottom of the Hand Controller and switch the Destination sign on.
- 9) Once the Destination sign is turned on all the display segments will flash, the Hand Controller will beep once and display the firmware version. E.g. F706
The Hand Controller will display: Pro S and then display: Pro U
The Hand Controller will next display: USB and then display: File 1
The Hand Controller will start counting the routes as it downloads them.
Once the process is completed the Hand Controller will display: Done

Example of message file:

0001 OR TAMBO
0002 JOHANNESBURG
0003 CAPE TOWN
0010 WINDHOEK
1000 HARARE
1001 MAPUTO