

NTX-Gateway TX/RX Test Tool

1. Plug usb flash drive to gateway and copy freqset6 & freqset8

a. `cp /media/pi/[FLASH_DRIVE_NAME]/freqset* .`

2. To test with 6 Channels

a. Get help

i. `sudo ./freqset6 -h`

usage: freqset6 -chn=0~7

0: TX(253.10), RX(10.10) [Default]

1: TX(253.26), RX(10.26)

2: TX(253.42), RX(10.42)

3: TX(253.58), RX(10.58)

4: TX(253.74), RX(10.74)

5: TX(253.90), RX(10.90)

b. Set TX/RX freq

i. `sudo ./freqset6 -chn=X`

3. 8 Channels

a. Get help

i. `sudo ./freqset8 -h`

usage: freqset8 -chn=0~7

0: TX(257.10), RX(10.10) [Default]

1: TX(257.26), RX(10.26)

2: TX(833.10), RX(10.10)

3: TX(833.26), RX(10.26)

4: TX(257.10), RX(204.10)

5: TX(257.26), RX(204.26)

6: TX(833.10), RX(204.10)

7: TX(833.26), RX(204.26)

b. Set TX/RX freq

i. `sudo ./freqset8 -chn=X`