

Fadercraft Control XL — Quickstart

Thanks for getting **Control XL** — a Max for Live device that turns your Novation Launch Control XL MK3 into a performance instrument: switchable Mixer and Instrument layers, one-touch cross-mode jumps, and automatic Solo Follow.

What's in this bundle

- `XL_Performance.amxd` — the Max for Live device. Everything it needs is bundled inside, so there are no extra files to keep next to it.
- `custom-modes/` — 14 Custom Modes for your controller (1–10 = instruments, 11–14 = mixer).
- `XL_Performance_starter.als` — a ready Live Set to start from.
- This Quickstart.

Requirements

- Ableton Live 11 or later, **with Max for Live**.
- Novation Launch Control XL **MK3**.

Setup (about 5 minutes)

1. Load the Custom Modes onto your LCXL MK3. Open Novation **Components**, connect the controller, and import every file in `custom-modes/` (one mode per file): slots **1–10** for the instrument pages and **11–14** for the mixer pages.

2. Add the device to a MIDI track. Open `XL_Performance_starter.als`, or drag `XL_Performance.amxd` onto a MIDI track in your own set.

3. Set the track's MIDI routing — this is the step most people miss. On the track that holds the device, set:

- **MIDI From** → *Launch Control XL MK3 (DAW)*
- **MIDI To** → *Launch Control XL MK3 (DAW)*
- **Channel** → *All*
- **Monitor** → *In*

Without this routing the device receives no MIDI and the controller will not respond.

4. Turn it on. Enable **Active** on the device. Solo Follower starts working: this track stays soloed alongside any track you solo, and focus follows the track you soloed last.

Using it

- The on-screen controls (**Daw** , **Prelisten** , **Page** , **Bank fx** , **Hold** , and the **11–14** tabs) mirror the hardware, so you can drive modes from the screen as well.
- Switch freely between instrument and mixer modes. The one-touch cross-mode jump takes you to the other layer and back to exactly where you were.

Updates

When a newer version is available, a mint **"New Version"** label appears at the top of the device. Click it to open the download page and grab the update.

Troubleshooting

The controller doesn't respond, or modes don't switch. Almost always this is the MIDI routing from step 3. Re-check that **MIDI From** and **MIDI To** are both set to *Launch Control XL MK3 (DAW)*, **Channel** is *All*, and the track **Monitor** is *In*.

Questions or trouble? Email support@fadercraft.com.