



Pin	Name	Direction	Description	
1	GND	-	Common ground	
2	VIN	PWR IN	4V – 20V system supply input <sup>1</sup>	
3	USB.VCC	PWR IN	5V system supply input <sup>1</sup> from USB bus. Using this pin will enable the FTDI USB. Use the VIN pin instead to disable the FTDI USB.	
4	USB.D+	1/0	USB data positive line (Serial 0)	
5	GPS PPS	1/0	GPS time synchronization output pulse (1Hz, 10% duty cycle)	
6	USB.D-	1/0	USB data negative line (Serial 0)	
7	G3/Tx0/R85Tx1-	0	Serial 0 output (TTL or RS232) <sup>2</sup> Serial 1 output- (RS485) <sup>3</sup>	
8	G7/Tx1/485Tx1+	0	Serial 1 output (TTL or RS232) <sup>3</sup> Serial 1 output+ (RS485).	
9	G4/Rx0/485Rx1-	I	Serial 0 input (TTL or RS232) <sup>2</sup> Serial 1 input- (RS485) <sup>3</sup>	
10	G6/Rx1/485Rx1+	I	Serial 1 input (TTL or RS232) <sup>3</sup> Serial 1 input+ (RS485) <sup>3</sup> .	
11	G1/CANL <sup>4</sup> /Rx2 <sup>4</sup>	I/O	High level (CAN bus) <sup>4</sup> . Serial 2 input (TTL) <sup>4</sup> .	
12	G2/CANH <sup>4</sup> /Tx2 <sup>4</sup> /STROBE	1/0	Low level (CAN bus) <sup>4</sup> . Serial 2 output (TTL) <sup>4</sup> . Strobe time sync input.	

<sup>&</sup>lt;sup>1</sup> The system can be powered by either VIN or USB.VCC.

PROPRIETARY AND COMPETITION SENSITIVE

THE INFORMATION CONTAINED IN THIS DOCUMENT IS THE SOLE PROPERTY OF INERTIAL SENSE. INCIDENTAL REPRODUCTION FOR THE RUD USER'S INTERNAL USE IS ALLOWED. ALL OTHER REPRODUCTION AND/OR DISSEMINATION IS PROHIBITED WITHOUT THE PRIOR WRITTEN CONSENT OF INERTIAL SENSE.

5

UNLESS OTHERWISE SPECIFIED:		NAME	DATE	Inertial Sense					
DIMENSIONS ARE IN INCHES	DRAWN	LM	4/20/2018	72 N 72			INERTIALSENSE micro navigation systems		
TOLERANCES: FRACTIONAL ± 1/8 PECIMAN AVV +0.005	CHECKED	Х	Х	TITLE:					
DECIMAL .XX ±0.01 .XXX ±0.005 ANGLES ±1°	ENG APPR.	Х	Х	''''''	Ruggedized uINS				
DO NOT SCALE DRAWING  MATERIAL	MFG APPR.	Х	Х	Pinout					
X	COMMENTS:			FINOUI					
THIRD ANGLE PROJECTION				SIZE	DWG	. NO.		REV	
\ \_				<b>A</b>		IS-RUG-1.1		Α	
⊕ — —			SCALE: 8:1		SHEET 1 OF 1				

C:\Users\Lamym\Dropbox\Projects\|S Mechanica\\Rugged uINS\CAD\df |S-uINS-10 Ruggedized uINS Pinout

4 3 2

<sup>&</sup>lt;sup>2</sup> Serial 0 is configured with SMT jumpers for TTL, RS232, or FTDI USB (default, USB.D+ and USB.D-).

<sup>&</sup>lt;sup>3</sup> Serial 1 is configured with SMT jumpers for TTL, RS232(default), RS485, or CAN.

<sup>&</sup>lt;sup>4</sup> Only available with uINS-3.2 and later.