

Programming Quick Guide

DFR0314 Barcode Reader

Factory Default Settings

Function	Default
Interface	Keyboard Mode
Reading Mode	GoodReadOFF
RS232 BAUD Rate	9600
Data Bits	8 Data Bits
Stop Bits	1 Bit
Handshaking	RTS/CTS Disable
Keyboard Wedge Mode	IBM PC/AT, PS/2
Output Characters Terminator	CR+LF
Time-out Between Characters	0 ms
Symbologies	UPC-A UPC-E EAN-13/JAN-13 EAN-8/JAN-8 CODE 39 CODE 128 CODABAR/NW7 Interleave 25
Language	US English
Bar Code ID	OFF
Reading Level	Bar Equals Low
Accuracy	1 Time
Buzzer Beep Tone	High
Sensitivity of Continuous	Fast
Notebook Function	Disable
Reverse Output Characters	Disable

Set All Defaults



%%+/2

Version Information



%%+/5

Symbologies Selection

UPC-A <ON>



%0A44

UPC-E <ON>



%0B08

EAN-13/JAN-13/ISBN-13 <ON>



%0A22

EAN-8/JAN-8 <ON>



%0A11

CODE 39 <ON>



%0E08

CODE 128 <ON>



%0F08

CODABAR/NW7 <ON>



%0J08

Interleaved 2 of 5 <ON>



%0G08

UPC-A OFF



%0A40

UPC-E OFF



%0B00

EAN-13/JAN-13/ISBN-13 OFF



%0A20

EAN-8/JAN-8 OFF



%0A10

CODE 39 OFF



%0E00

CODE 128 OFF



%0F00

CODABAR/NW7 OFF



%0J00

Interleaved 2 of 5 OFF



%0G00

CODE 93 ON



%0K08

China Postage ON



%0M08

Telepen ON



%0T08

GS1 DataBar Omnidirectional ON



%0U08

GS1 DataBar Limited ON



%0V08

GS1 DataBar Expanded ON



%0W08

Select All Bar Codes



%1A/+

CODE 93 <OFF>



%0K00

China Postage <OFF>



%0M00

Telepen <OFF>



%0T00

GS1 DataBar Omnidirectional <OFF>



%0U00

GS1 DataBar Limited <OFF>



%0V00


GS1 DataBar Expanded <OFF>



%0W00

Configuration Flow Chart

① Scan Start of Configuration.




② Scan all necessary labels for parameters that meet applications.


Interface Selection
RS232 Mode Parameters
Reading Mode Selection
Symbologies Selection



③ Scan End of Configuration to end the programming.



④ To permanently save the settings by your programmed, just scan label for Save Parameters.



Interface Selection

<Keyboard Mode>



%0U0

RS232 Mode



%0U8

USB Mode



%0X08

Reading Mode Selection

<Good Read OFF>



%0271

Trigger ON/OFF



%0270

Continuous/Trigger OFF



%0272

Testing



%0275

Continuous/Auto Power On



%0273

Flash



%0274

Flash/Auto Power On



%0276

Auto Sense (Option)



%0F8

Select Terminator

<CR+LF>



%7S2+

None



%7S7+

CR



%7S0+

LF



%7S1+

Space



%7S4+

HT(TAB)



%7S3+

STX-ETX



%7S5+

RS232 Mode Parameters

A> Set Up BAUD Rate

1200



%0Y71

2400



%0Y72

4800



%0Y73

19200



%0Y74

B> Set Up Data Bits
7 Data Bits



%0Y80

<8 Data Bits>



%0Y88

2 Bits



%0Y00

Even



%0YN2

Odd



%0YN3

Space



%0YN0

E> Handshaking
RTS/CTS Enable



%0188

ACK/NAK Enable



%0144

XON/XOFF Enable



%03K4

<RTS/CTS Disable>



%0180

<ACK/NAK Disable>



%0140

<XON/XOFF Disable>



%03K0