

# **Application Notes**

Version: Preliminary V0.6

Date: Mar. 11th 2011

#### ILI TECHNOLOGY CORP.

8F, No.38, Taiyuan St., Jhubei City, Hsinchu County 302, Taiwan, R.O.C Tel.886-3-5600099; Fax.886-3-5600055 http://www.ilitek.com




1. LGD 2.6" PANEL	3
1.1 FPC APPLICATION CIRCUIT	
1.2 LG 2.6" INITIAL CODE	4
2. BOE 2.0" 2.4" PANEL	8
2.1 FPC APPLICATION CIRCUIT	8
2.2 BOE 2.0" INITIAL CODE	9
2.3 BOE 2.4" INITIAL CODE	13
3. TM 2.2" 2.4" PANEL	17
3.1 FPC APPLICATION CIRCUIT	17
REVISION HISTORY	21





### 1. LGD 2.6" Panel

### 1.1 FPC Application Circuit



V0.6





#### 1.2 LG 2.6" Initial Code

```
void ILI9341_LG2.6_Initial(void)
{
// VCI=2.8V
//******* Reset LCD Driver *********//
LCD_nRESET = 1;
delayms(1);
                                      // Delay 1ms
LCD nRESET = 0;
delayms(10);
                                      // Delay 10ms // This delay time is necessary
LCD_nRESET = 1;
delayms(120);
                                      // Delay 120 ms
//******** Start Initial Sequence ********//
LCD_ILI9341_CMD(0xCB);
LCD_ILI9341_ Parameter (0x39);
LCD_ILI9341_ Parameter (0x2C);
LCD_ILI9341_ Parameter (0x00);
LCD ILI9341 Parameter (0x34);
LCD_ILI9341_ Parameter (0x02);
LCD_ILI9341_CMD(0xCF);
LCD ILI9341 Parameter (0x00);
LCD_ILI9341_ Parameter (0XC1);
LCD_ILI9341_ Parameter (0X30);
LCD_ILI9341_CMD(0xE8);
LCD_ILI9341_ Parameter (0x85);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x78);
LCD_ILI9341_CMD(0xEA);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_CMD(0xED);
LCD_ILI9341_ Parameter (0x64);
LCD_ILI9341_ Parameter (0x03);
LCD_ILI9341_ Parameter (0X12);
LCD ILI9341 Parameter (0X81)
```





```
LCD ILI9341 CMD(0xF7);
LCD_ILI9341_ Parameter (0x20);
LCD_ILI9341_CMD(0xC0);
                                      //Power control
LCD_ILI9341_ Parameter (0x23);
                                      //VRH[5:0]
LCD_ILI9341_CMD(0xC1);
                                      //Power control
LCD_ILI9341_ Parameter (0x10);
                                      //SAP[2:0];BT[3:0]
LCD_ILI9341_CMD(0xC5);
                                      //VCM control
LCD_ILI9341_ Parameter (0x2B);
LCD_ILI9341_ Parameter (0x2B);
//LCD_ILI9341_CMD(0xC7);
                                      //VCM control2
//LCD ILI9341 Parameter (0xC0);
LCD ILI9341 CMD(0x36);
                                      // Memory Access Control
LCD_ILI9341_ Parameter (0x48);
LCD_ILI9341_CMD(0xB1);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x1B);
LCD_ILI9341_CMD(0xB6);
                                      // Display Function Control
LCD_ILI9341_ Parameter (0x0A);
LCD_ILI9341_ Parameter (0x02);
                                      // 3Gamma Function Disable
LCD_ILI9341_CMD(0xF2);
LCD ILI9341 Parameter (0x00);
LCD_ILI9341_CMD(0x26);
                                      //Gamma curve selected
LCD_ILI9341_ Parameter (0x01);
LCD_ILI9341_CMD(0xE0);
                                      //Set Gamma
LCD_ILI9341_ Parameter (0x0F);
LCD_ILI9341_ Parameter (0x31);
LCD_ILI9341_ Parameter (0x2B);
LCD_ILI9341_ Parameter (0x0C);
```





```
LCD ILI9341 Parameter (0x0E);
LCD_ILI9341_ Parameter (0x08);
LCD_ILI9341_ Parameter (0x4E);
LCD ILI9341 Parameter (0xF1);
LCD_ILI9341_ Parameter (0x37);
LCD_ILI9341_ Parameter (0x07);
LCD_ILI9341_ Parameter (0x10);
LCD_ILI9341_ Parameter (0x03);
LCD_ILI9341_ Parameter (0x0E);
LCD_ILI9341_ Parameter (0x09);
LCD_ILI9341_ Parameter (0x00);
LCD ILI9341 CMD(0XE1);
                                       //Set Gamma
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x0E);
LCD ILI9341 Parameter (0x14);
LCD_ILI9341_ Parameter (0x03);
LCD_ILI9341_ Parameter (0x11);
LCD_ILI9341_ Parameter (0x07);
LCD_ILI9341_ Parameter (0x31);
LCD_ILI9341_ Parameter (0xC1);
LCD_ILI9341_ Parameter (0x48);
LCD_ILI9341_ Parameter (0x08);
LCD_ILI9341_ Parameter (0x0F);
LCD_ILI9341_ Parameter (0x0C);
LCD_ILI9341_ Parameter (0x31);
LCD_ILI9341_ Parameter (0x36);
LCD_ILI9341_ Parameter (0x0F);
LCD ILI9341 CMD(0x11);
                                       //Exit Sleep
Delayms(120);
LCD_ILI9341_CMD(0x29);
                                       //Display on
}
```





```
void LCD_Enter Sleep_ILI9341(void)
{
LCD_ILI9341_CMD(0x28);  // Display off
Delayms(20);
LCD_ILI9341_CMD(0x10);  // Enter Sleep mode
}

void LCD_Exit Sleep_ILI9341(void)
{
LCD_ILI9341_CMD(0x11);  // Sleep out
Delayms(120);
LCD_ILI9341_CMD(0x29);  // Display on
}
```


V0.6





### 2. BOE 2.0" 2.4" Panel

### 2.1 FPC Application Circuit









#### 2.2 BOE 2.0" Initial Code

```
void ILI9341_BOE2.0_Initial(void)
{
// VCI=2.8V
//******* Reset LCD Driver *********//
LCD_nRESET = 1;
delayms(1);
                                      // Delay 1ms
LCD nRESET = 0;
delayms(10);
                                      // Delay 10ms // This delay time is necessary
LCD_nRESET = 1;
delayms(120);
                                      // Delay 120 ms
//******** Start Initial Sequence ********//
LCD_ILI9341_CMD(0xCF);
LCD_ILI9341_ Parameter (0x00);
LCD ILI9341 Parameter (0x99);
LCD_ILI9341_ Parameter (0X30);
LCD_ILI9341_CMD(0xED);
LCD_ILI9341_ Parameter (0x64);
LCD_ILI9341_ Parameter (0x03);
LCD ILI9341 Parameter (0X12);
LCD_ILI9341_ Parameter (0X81);
LCD_ILI9341_CMD(0xE8);
LCD_ILI9341_ Parameter (0x85);
LCD_ILI9341_ Parameter (0x10);
LCD_ILI9341_ Parameter (0x78);
LCD_ILI9341_CMD(0xCB);
LCD_ILI9341_ Parameter (0x39);
LCD_ILI9341_ Parameter (0x2C);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x34);
LCD_ILI9341_ Parameter (0x02);
LCD_ILI9341_CMD(0xF7);
LCD_ILI9341_ Parameter (0x20);
```





```
LCD ILI9341 CMD(0xEA);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_CMD(0xC0);
                                      //Power control
LCD_ILI9341_ Parameter (0x26);
                                      //VRH[5:0]
LCD_ILI9341_CMD(0xC1);
                                      //Power control
LCD_ILI9341_ Parameter (0x12);
                                      //SAP[2:0];BT[3:0]
LCD_ILI9341_CMD(0xC5);
                                      //VCM control
LCD_ILI9341_ Parameter (0x2B);
LCD ILI9341 Parameter (0x2C);
LCD_ILI9341_CMD(0xC7);
                                      //VCM control2
LCD_ILI9341_ Parameter (0xC4);
LCD ILI9341 CMD(0x36);
                                      // Memory Access Control
LCD_ILI9341_ Parameter (0x08);
LCD_ILI9341_CMD(0xB1);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x1B);
LCD_ILI9341_CMD(0xB6);
                                      // Display Function Control
LCD_ILI9341_ Parameter (0x0A);
LCD_ILI9341_ Parameter (0xA2);
LCD_ILI9341_CMD(0xF2);
                                      // 3Gamma Function Disable
LCD ILI9341 Parameter (0x00);
LCD_ILI9341_CMD(0x26);
                                      //Gamma curve selected
LCD_ILI9341_ Parameter (0x01);
LCD ILI9341 CMD(0xE0);
                                      //Set Gamma
LCD_ILI9341_ Parameter (0x0F);
LCD_ILI9341_ Parameter (0x24);
LCD_ILI9341_ Parameter (0x21);
LCD_ILI9341_ Parameter (0x0A);
```





```
LCD ILI9341 Parameter (0x0E);
LCD_ILI9341_ Parameter (0x09);
LCD_ILI9341_ Parameter (0x51);
LCD ILI9341 Parameter (0xA9);
LCD_ILI9341_ Parameter (0x44);
LCD_ILI9341_ Parameter (0x07);
LCD_ILI9341_ Parameter (0x10);
LCD_ILI9341_ Parameter (0x03);
LCD_ILI9341_ Parameter (0x2C);
LCD_ILI9341_ Parameter (0x0B);
LCD_ILI9341_ Parameter (0x00);
LCD ILI9341 CMD(0XE1);
                                       //Set Gamma
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x1B);
LCD ILI9341 Parameter (0x1E);
LCD_ILI9341_ Parameter (0x05);
LCD_ILI9341_ Parameter (0x11);
LCD_ILI9341_ Parameter (0x06);
LCD_ILI9341_ Parameter (0x2E);
LCD_ILI9341_ Parameter (0x56);
LCD_ILI9341_ Parameter (0x3B);
LCD_ILI9341_ Parameter (0x08);
LCD_ILI9341_ Parameter (0x0F);
LCD_ILI9341_ Parameter (0x0C);
LCD_ILI9341_ Parameter (0x13);
LCD_ILI9341_ Parameter (0x14);
LCD_ILI9341_ Parameter (0x0F);
LCD ILI9341 CMD(0x11);
                                       //Exit Sleep
Delayms(120);
LCD_ILI9341_CMD(0x29);
                                       //Display on
}
```





```
void LCD_Enter Sleep_ILI9341(void)
{
LCD_ILI9341_CMD(0x28);  // Display off
delayms(20);
LCD_ILI9341_CMD(0x10);  // Enter Sleep mode
}
void LCD_Exit Sleep _ILI9341(void)
{
LCD_ILI9341_CMD(0x11);  // Sleep out
Delayms(120);
LCD_ILI9341_CMD(0x29);  // Display on
}
```





### 2.3 BOE 2.4" Initial Code

```
void ILI9341_BOE2.4_Initial(void)
{
// VCI=2.8V
//************ Reset LCD Driver ***********//
LCD_nRESET = 1;
delayms(1);
                                      // Delay 1ms
LCD_nRESET = 0;
                                      // Delay 10ms // This delay time is necessary
delayms(10);
LCD_nRESET = 1;
delayms(120);
                                      // Delay 120 ms
//******* Start Initial Sequence *******//
LCD_ILI9341_CMD(0xCF);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x81);
LCD_ILI9341_ Parameter (0X30);
LCD_ILI9341_CMD(0xED);
LCD_ILI9341_ Parameter (0x64);
LCD_ILI9341_ Parameter (0x03);
LCD_ILI9341_ Parameter (0X12);
LCD_ILI9341_ Parameter (0X81);
LCD_ILI9341_CMD(0xE8);
LCD_ILI9341_ Parameter (0x85);
LCD_ILI9341_ Parameter (0x10);
LCD_ILI9341_ Parameter (0x78);
LCD_ILI9341_CMD(0xCB);
LCD_ILI9341_ Parameter (0x39);
LCD_ILI9341_ Parameter (0x2C);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x34);
LCD_ILI9341_ Parameter (0x02);
LCD_ILI9341_CMD(0xF7);
LCD_ILI9341_ Parameter (0x20);
```





```
LCD_ILI9341_CMD(0xEA);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_CMD(0xB1);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x1B);
LCD_ILI9341_CMD(0xB6);
                                      // Display Function Control
LCD_ILI9341_ Parameter (0x0A);
LCD_ILI9341_ Parameter (0xA2);
LCD_ILI9341_CMD(0xC0);
                                      //Power control
LCD_ILI9341_ Parameter (0x21);
                                      //VRH[5:0]
LCD_ILI9341_CMD(0xC1);
                                      //Power control
LCD_ILI9341_ Parameter (0x11);
                                      //SAP[2:0];BT[3:0]
                                      //VCM control
LCD_ILI9341_CMD(0xC5);
LCD_ILI9341_ Parameter (0x3F);
LCD_ILI9341_ Parameter (0x3C);
LCD_ILI9341_CMD(0xC7);
                                      //VCM control2
LCD_ILI9341_ Parameter (0Xb5);
LCD_ILI9341_CMD(0x36);
                                      // Memory Access Control
LCD_ILI9341_ Parameter (0x48);
LCD ILI9341 CMD(0xF2);
                                      // 3Gamma Function Disable
LCD_ILI9341_ Parameter (0x00);
LCD ILI9341 CMD(0x26);
                                      //Gamma curve selected
LCD_ILI9341_ Parameter (0x01);
LCD_ILI9341_CMD(0xE0);
                                      //Set Gamma
LCD_ILI9341_ Parameter (0x0F);
LCD_ILI9341_ Parameter (0x26);
LCD_ILI9341_ Parameter (0x24);
```





```
LCD ILI9341 Parameter (0x0B);
LCD_ILI9341_ Parameter (0x0E);
LCD_ILI9341_ Parameter (0x09);
LCD ILI9341 Parameter (0x54);
LCD_ILI9341_ Parameter (0XA8);
LCD_ILI9341_ Parameter (0x46);
LCD_ILI9341_ Parameter (0x0C);
LCD_ILI9341_ Parameter (0x17);
LCD_ILI9341_ Parameter (0x09);
LCD_ILI9341_ Parameter (0x0F);
LCD_ILI9341_ Parameter (0x07);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_CMD(0XE1);
                                       //Set Gamma
LCD_ILI9341_ Parameter (0x00);
LCD ILI9341 Parameter (0x19);
LCD_ILI9341_ Parameter (0x1B);
LCD_ILI9341_ Parameter (0x04);
LCD_ILI9341_ Parameter (0x10);
LCD_ILI9341_ Parameter (0x07);
LCD_ILI9341_ Parameter (0x2A);
LCD_ILI9341_ Parameter (0x47);
LCD_ILI9341_ Parameter (0x39);
LCD_ILI9341_ Parameter (0x03);
LCD_ILI9341_ Parameter (0x06);
LCD_ILI9341_ Parameter (0x06);
LCD_ILI9341_ Parameter (0x30);
LCD_ILI9341_ Parameter (0x38);
LCD_ILI9341_ Parameter (0x0F);
LCD_ILI9341_CMD(0x11);
                                      //Exit Sleep
Delayms(120);
LCD_ILI9341_CMD(0x29);
                                       //Display on
}
```





V0.6

```
void LCD_Enter Sleep_ILI9341(void)
{
LCD_ILI9341_CMD(0x28);  // Display off
delayms(20);
LCD_ILI9341_CMD(0x10);  // Enter Sleep mode
}


void LCD_Exit Sleep _ILI9341(void)
{
LCD_ILI9341_CMD(0x11);  // Sleep out
Delayms(120);
LCD_ILI9341_CMD(0x29);  // Display on
}
```





### 3. TM 2.2" 2.4" Panel

### 3.1 FPC Application Circuit



V0.6







#### 3.2 Tianma 2.4" Initial Code

LCD\_ILI9341\_ Parameter (0x20);

```
void ILI9341_Tianma2.4_Initial(void)
// VCI=2.8V
//******* Reset LCD Driver *********//
LCD nRESET = 1;
delayms(1);
                                      // Delay 1ms
LCD nRESET = 0;
delayms(10);
                                      // Delay 10ms // This delay time is necessary
LCD_nRESET = 1;
delayms(120);
                                      // Delay 120 ms
//******** Start Initial Sequence ********//
LCD_ILI9341_CMD(0xCF);
LCD ILI9341 Parameter (0x00);
LCD_ILI9341_ Parameter (0x81);
LCD_ILI9341_ Parameter (0X30);
LCD_ILI9341_CMD(0xED);
LCD ILI9341 Parameter (0x64);
LCD_ILI9341_ Parameter (0x03);
LCD_ILI9341_ Parameter (0X12);
LCD ILI9341 Parameter (0X81);
LCD ILI9341 CMD(0xE8);
LCD ILI9341 Parameter (0x85);
LCD_ILI9341_ Parameter (0x10);
LCD_ILI9341_ Parameter (0x7A);
LCD ILI9341 CMD(0xCB);
LCD_ILI9341_ Parameter (0x39);
LCD_ILI9341_ Parameter (0x2C);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x34);
LCD_ILI9341_ Parameter (0x02);
LCD ILI9341 CMD(0xF7);
```





```
LCD_ILI9341_CMD(0xEA);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_CMD(0xC0);
                                      //Power control
LCD_ILI9341_ Parameter (0x21);
                                      //VRH[5:0]
LCD_ILI9341_CMD(0xC1);
                                      //Power control
LCD_ILI9341_ Parameter (0x11);
                                      //SAP[2:0];BT[3:0]
LCD_ILI9341_CMD(0xC5);
                                      //VCM control
LCD ILI9341 Parameter (0x3F);
LCD_ILI9341_ Parameter (0x3C);
LCD_ILI9341_CMD(0xC7);
                                      //VCM control2
LCD_ILI9341_ Parameter (0Xa7);
LCD_ILI9341_CMD(0x36);
                                      // Memory Access Control
LCD_ILI9341_ Parameter (0x48);
LCD_ILI9341_CMD(0xB1);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_ Parameter (0x1B);
LCD_ILI9341_CMD(0xB6);
                                      // Display Function Control
LCD_ILI9341_ Parameter (0x0A);
LCD_ILI9341_ Parameter (0xA2);
LCD ILI9341 CMD(0xF2);
                                      // 3Gamma Function Disable
LCD_ILI9341_ Parameter (0x00);
LCD ILI9341 CMD(0x26);
                                      //Gamma curve selected
LCD_ILI9341_ Parameter (0x01);
LCD_ILI9341_CMD(0xE0);
                                      //Set Gamma
LCD_ILI9341_ Parameter (0x0F);
LCD_ILI9341_ Parameter (0x23);
LCD_ILI9341_ Parameter (0x1F);
```





```
LCD ILI9341 Parameter (0x0B);
LCD_ILI9341_ Parameter (0x0E);
LCD_ILI9341_ Parameter (0x08);
LCD ILI9341 Parameter (0x4B);
LCD_ILI9341_ Parameter (0XA8);
LCD_ILI9341_ Parameter (0x3B);
LCD_ILI9341_ Parameter (0x0A);
LCD_ILI9341_ Parameter (0x14);
LCD_ILI9341_ Parameter (0x06);
LCD_ILI9341_ Parameter (0x10);
LCD_ILI9341_ Parameter (0x09);
LCD_ILI9341_ Parameter (0x00);
LCD_ILI9341_CMD(0XE1);
                                       //Set Gamma
LCD_ILI9341_ Parameter (0x00);
LCD ILI9341 Parameter (0x1C);
LCD_ILI9341_ Parameter (0x20);
LCD_ILI9341_ Parameter (0x04);
LCD_ILI9341_ Parameter (0x10);
LCD_ILI9341_ Parameter (0x08);
LCD_ILI9341_ Parameter (0x34);
LCD_ILI9341_ Parameter (0x47);
LCD_ILI9341_ Parameter (0x44);
LCD_ILI9341_ Parameter (0x05);
LCD_ILI9341_ Parameter (0x0B);
LCD_ILI9341_ Parameter (0x09);
LCD_ILI9341_ Parameter (0x2F);
LCD_ILI9341_ Parameter (0x36);
LCD_ILI9341_ Parameter (0x0F);
LCD_ILI9341_CMD(0x11);
                                      //Exit Sleep
Delayms(120);
LCD_ILI9341_CMD(0x29);
                                       //Display on
}
```





### **Revision History**

Revision History

Version No.	Date	Page	Description
V01	2010/09/14	All	New Creation
V02	2010/10/26	All	Modified VCI1 → GND · C31M → GND
			Add BOE2.0" BOE2.4" LG2.6" initial code
V03	2010/12/20	All	Remove command EF
V0.4	2011/02/20	ALL	Add 1uF capacitor in Vcore pad
V0.5	2011/03/08	ALL	Add Tianma initial code and modify LG/BOE initial code
V0.6	2011/03/11	ALL	Modify TM 2.4 and BOE initial code