

DeepRobotics Jueying Lite3 — Operating from a web browser

No software installation is required on the operating device (phone, tablet or laptop). The device only needs to be on the **same network as the console computer**: the robot's Wi-Fi (192.168.2.x) or the same LAN (192.168.1.x).

1. Requirements

- The console computer is powered on, on the robot's Wi-Fi or on the same LAN, and the Lite3 Pilot console is running (it serves the web interface on port **8123**).
- Your device (phone/tablet/laptop) is:
 - on the **robot's Wi-Fi** (the hotspot from the robot's QR label), or
 - on the **same LAN** as the console computer.
- No web server, no VPN, no internet access is needed — everything is local.

2. Find the console address

1. On the console computer, the address to use is its own IP on the network that your device shares:
 - on the robot's Wi-Fi: e.g. 192.168.2.22
 - on the same LAN: e.g. 192.168.1.210
2. Console URL format: **http://<console-computer-IP>:8123**
Example: http://192.168.2.22:8123

3. Open and connect

1. Open that URL in the browser on your device.
2. Check the robot IP shown under **Advanced** → **Robot IP**: it must be the motion host of the network you are on:
 - robot Wi-Fi: **192.168.2.1**
 - ethernet/LAN: **192.168.1.120**
3. Press  **Connect**. Wait for  **Connected** (the status line also shows the ping result).
4. The camera pane opens automatically (when the robot's camera service is running).
5. Operating controls:  **STAND** /  **SIT**, the action buttons (dance, hello, flips...), the two joysticks (left: forward/back + turn, right: slide), **STOP** and **E-STOP**.

4. Before you move the robot

- Clear the area (about 5 m) and keep the physical E-stop within reach — it always overrides the software.
- The robot must be **standing**: driving commands are ignored while it is sitting or lying down.
- If the header shows **E-STOP** latched, press  **Return** to re-arm. While latched, no command is sent.
- Both joysticks are spring-centred: release = stop. Holding a position keeps driving until released.

5. Troubleshooting

- **The page does not open**: your device is not on the same network as the console computer, or the IP is wrong. Re-join the robot Wi-Fi / LAN and re-check the IP.

- **Page opens but not connected:** verify Advanced → Robot IP matches the network (2.1 on robot Wi-Fi, 1.120 on LAN), and that the robot is powered and awake.
- **Buttons are greyed until connected:** expected. They enable automatically on connect.
- **Commands seem to do nothing:** robot not standing, or software E-stop latched (press ↻ Return). Note that UDP gives no acknowledgement — confirm motion visually.
- **No camera:** the robot's camera service must be running on the robot. The console retries automatically every ~8 s.
- **No battery / IMU readout:** requires a one-time setting on the robot (telemetry target in `~/jy_exe/conf/network.toml`). Driving works without it.

Security note: the console is a local service without authentication — keep it on trusted, local networks and close the browser session when finished.