Balance Bike Workshop 2

# Install the CP2102 driver before class

Follow the file names below, then check the serial port.

## 1 WINDOWS 10 / 11

**CP210x Universal Windows Driver**

1. Download the Universal Windows Driver
2. Extract the downloaded ZIP file
3. Right-click silabser.inf in the main folder
4. Select Install (Win 11: Show more options)
5. Plug in CP2102; open Device Manager
6. Under Ports (COM & LPT), note new COM

Official Silicon Labs download

**OPEN DRIVER PAGE >**

## 2 macOS 13+

**CP210x VCP Mac OSX Driver**

1. Download the VCP Mac OSX Driver
2. Extract ZIP; open macOS_VCP_Driver
3. Open SiLabsUSBDriverDisk.dmg
4. Run Install CP210x VCP Driver.app
5. Follow prompts; allow access if asked
6. Plug in CP2102; select new USB serial port

Official Silicon Labs download

**OPEN DRIVER PAGE >**

**READY WHEN: The new CP2102 port appears in the IMU Visualizer's Connect list.**