

设备安装设置

房间控制箱制作

组成

- 1P 空开
- 24V 轨道电源
- 4路 开关量转RS485
- LoraRouter

设置

站号设置

== EXAMPLE ==

```
BOXID PF1 - 1
UNITID      1
```

lora 设置

- 信道
 - 系统一 10
 - 系统二 30
 - 系统三 50
- 输出帧头 不使能
- 密钥 718293
- 节点类型 路由节点

模块RS485发送 设置无返回值
AT+BACK=0x00,0

变频器控制箱制作

组成

- 1P 空开
- 24V 轨道电源
- 6路 继电器输出模块
- 6路 4-20mA 输出模块
- LoraRouter

设置

站号设置

- 4-20mA 输出模块 10
- 继电器输出模块 11

lora 设置

- 信道
 - 系统一 10
 - 系统二 30
 - 系统三 50 (变频器在系统三)
- 输出帧头 不使能
- 密钥 718293
- 节点类型 路由节点

模块RS485发送 设置无返回值
AT+BACK=0x00,0

中央控制箱制作

组成

- 1P 空开
- 3位 PDU 插排

- 12V 轨道电源
- LoraEnd x3
- RS485网关 x3
- 无线路由器
- 电脑

设置

网关IP设置

系统	IP
通讯系统一	192.168.1.100
通讯系统二	192.168.1.101
通讯系统三	192.168.1.102

附上设置图：

The screenshot shows a web-based configuration interface for a DTU device. The interface has a dark blue header and footer. On the left is a sidebar menu with the following items: 本机IP设置, 端口参数, 业务心跳包, 业务注册包, HTTP 参数, DTU云与数据转换 (highlighted in blue), 轮询设置1, 轮询设置2, and 模块管理. The main content area is titled '参数' (Parameters) and contains the following fields: '设备云账号' (Device Cloud Account) with value '20060248', '设备云密码' (Device Cloud Password) with value '123456', and '数据转换' (Data Conversion) with a dropdown menu set to '使能Modbus RTU转Modbus TCP'. Below these fields are two buttons: '保存设置' (Save Settings) and '不保存设置' (Do Not Save Settings). On the right side of the main area is a '帮助' (Help) section with the text: '云工作模式: DTU 云模式或IOT 云模式的工作模式在端口参数工作模式里面设置'.

参数		
波特率:	115200	bps
数据位:	8	bit
校验位:	None	
停止位:	1	bit
DSCTIME:	120	(0,10~65535)
ACKTIME:	1800	(0,10~65535)
PortTIME:	1800	(0,10~65535)
定时重启:	0	(0,10~2592000)
LINKTIME:	3	(0~65535)
网络数据头:	关闭网络数据头	
主本地端口:	12000	(0~65535)
主远程端口:	10123	(1~65535)
工作方式:	TCP Server	
设备账号:	admin	
设备密码:	12345678	
主远程服务器地址:	192.168.0.73	
保存设置 不保存设置		

参数		
DHCP:	静态IP	
本机IP:	192.168.50.110	
子网掩码:	255.255.255.0	
网关地址:	192.168.50.1	
DNS地址:	114.114.114.114	
MAC地址:	DC-04-5A-62-30-1B	
版本号:	KS-401_V1.0.3_D20260416	
保存设置 不保存设置		

DHCP:
开启后,设备IP将会从DHCP服务器租借,IP地址将不再是192.168.0.80,可以通过Reload恢复

MAC:
MAC地址只能通过串口修改

路由器参数

- 网关 192.168.1.1
- 子网掩码 255.255.255.0
- DNS 192.168.1.1
- DHCP 开启
- 无线酌情设置

Lora 设置

- 信道
 - 系统一 10
 - 系统二 30
 - 系统三 50
- 输出帧头 不使能
- 密钥 718293
- 节点类型 终端节点

模块RS485发送 设置无返回值
AT+BACK=0x00,0