

3.3.13 ~~gps set_start <start_type>~~

~~<start_type>: A string representing the way of how S76G/S78G starts to get position, so the string can be hot, warm or cold.~~

~~Response: Ok, if <start_type> string is valid.~~

~~Invalid, if <start_type> string is not valid.~~

~~Purpose:~~

- ~~a) There're 3 types for GPS/HYBRID starting and they are called as hot, warm and cold.~~
- ~~b) If user didn't use this command after "sip factory_reset", the default value is set at hot start.~~
- ~~c) After calling this command, the setting value would be stored into EEPROM immediately~~

~~Example:~~

~~gps set_start cold~~

~~>> Ok~~

~~gps get_mode~~

~~>> off cold 20 3000 kiwi gps~~

4. Example

This section gives several complete examples on how to use AcSiP command interface. All examples include many comments followed by double slash. This comments are for clearly explanation and should not be inputted to S76G through command interface

4.1 LoRaWAN™

4.1.1 ABP

// Set channel frequency channel number and frequency depends on server configuration

mac set ch_freq 0 926500000

>> Ok

mac set ch_freq 1 926700000

>> Ok

mac set ch_freq 2 926900000

>> Ok

...

```
// Set following according to LoRaWAN configuration
mac set_devaddr 00220009
>> Ok
mac set_nwkskey 965F6942F29C9EBE5747E25F07DA5114
>> Ok
mac set_appskey A46847D184323C21C992D8F9EF4B7CE9
>> Ok
```

```
// Activation by Personalization
mac join abp
>> Ok
>> accepted
```

```
// Send unconfirmed uplink on port 15
mac tx ucnf 15 1234
>> Ok
>> tx_ok
```

4.1.2 OTAA

```
// Set channel frequency channel number and frequency depends on server configuration
mac set_ch_freq 0 926500000
>> Ok
mac set_ch_freq 1 926700000
>> Ok
mac set_ch_freq 2 926900000
>> Ok
...
```

```
// Set following according to LoRaWAN configuration
mac set_deveui 9c65f9fffeabcd12
>> Ok
mac set_appeui 70B3D57ED000059E
>> Ok
mac set_appkey C1FE94B0F5F6A50E83015B3C45C933A9
>> Ok
```

// Over-the-Air Activation

mac join otaa

>> Ok

>> accepted

// Send unconfirmed uplink on port 15

mac tx ucnf 15 1234

>> Ok

>> tx_ok

//Auto Join Mode

(The next boot-up, it would try to join by OTAA for three times.)

mac set_auto_join on otaa 3

(The next boot-up, it would try to join by ABP (ABP only needs one-time joining)

mac set_auto_join on abp

(Disable Auto Join behavior)

mac set_auto_join off

(Don't forget to save the last setting above, or it would not take effect after reboot)

mac save

(Reset node and then Auto Join Mode starts)

sip reset

4.1.3 Confirmed Uplink and Downlink

// Send confirmed uplink on port 15

mac tx cnf 15 1234 // Send 0x12, 0x34 to server

>> Ok

>> tx_ok

mac tx cnf 15 1234

>> Ok

>> err // Fail to get confirm from server

mac tx cnf 15 1234

>> Ok

>> rx 15 6432 // Receive downlink (0x64, 0x32) from server on port 15