mode indicator Arm Joints left
safety override

USB

run factor dead man

joint up _

joint down

joint left

joint right

joint 7/gripper

joint 5/6

joint 3/4

joint 1/2

gripper joints

init/recover pairing

next mode

