IRONKERNEL EMBEDDED

Product Brief
Revision 10-27-2026

VITA 46.11 IPMC in Rust

Intelligent Platform Management Controller firmware for VPX plug-in modules: Tier-1, Tier-2 and Tier-3 on one Arm Cortex-M4F microcontroller, written entirely in Rust.

The IronKernel IPMC is the management controller firmware a VPX plug-in module needs to take part in an ANSI/VITA 46.11-2022 system. It answers the Chassis Manager on the redundant IPMB-A and IPMB-B buses, reports the module's identity, FRU inventory and sensors, runs the FRU state machine that controls payload power, and at Tier-2 and Tier-3 sends events and keeps a System Event Log. On the reference board it runs on a single STM32F401RE Arm Cortex-M4F microcontroller, with no FPGA, no RTOS and no C code. It is built natively and entirely in Rust with the standard Rust compiler (`rustc` 1.99.1, stable). The IPMI logic contains no hardware code, so the IPMC moves to other processors with a new board support layer: other Arm Cortex-M and Cortex-A CPUs, the Arm-based PIC32C microcontrollers, and the RISC-V soft processors Nios V and MicroBlaze V in an FPGA.

Highlights


- Memory-safe by construction: the Rust compiler rejects buffer overruns, use-after-free and data races at build time; the IPMI logic forbids `unsafe` code
- No heap, no RTOS, no C: all memory is fixed at build time
- Designed to meet DO-178C Level D (DAL-D), with a Level D plan, gap analysis and tool assessment
- Builds with the Ferrocene safety-qualified Rust compiler today, for programs that ask for a qualified toolchain
- Boot image validation: the bootloader checks the image's length and SHA-256 digest before every start
- Tier-1, Tier-2 and Tier-3 from one source tree
- Dual IPMB with per-bus queues, retries on the other bus and a duplicate cache
- Supply rails in volts and die temperature in degrees C
- PC emulator of the same IPMI code; 1,320 test cases, 1,253 tests run, 1,253 passed

At a glance

Item	Value
Standard	ANSI/VITA 46.11-2022, IPMI v2.0
Tiers	1, 2 and 3
Processor	STM32F401RE (reference board); ports to Arm, PIC32C, Nios V, MicroBlaze V
Flash used	141 KB runtime, 23 KB bootloader
RAM used	25 KB static
IPMB	two buses, 100 kHz; 400 kHz at Tier-3
Language	Rust, `no_std`; `rustc` 1.99.1 stable
PC build	emulator, x86-64

How it works

Figure 1. The IronKernel IPMC on the module (product-brief, sheet 1)



Each IPMB interrupt stores whole frames in a queue for its bus; the main loop merges both queues in arrival order, drops repeated requests through the duplicate cache, and answers each one. The IPMI logic (frame codec, link layer, commands, sensors, SDR, FRU state machine) has no hardware code, so it is tested on a PC and moves to another microcontroller with a new board support layer.

Area	Features
IPMB link	IPMB-A and IPMB-B, each with its own receive state; hardware I2C or bit-bang master; six tries per request, resent on the other bus; Set IPMB State; a build switch for strict VITA 46.11 or same-bus responses
Commands	the 13 Tier-1 mandatory commands and Broadcast Get Device ID; 4 more commands and event messages at Tier-2; 18 more at Tier-3 (Tiers, page 3)
Sensors and SDR	the VITA 46.11 mandatory sensors; five supply rails in volts and the die temperature in degrees C, with Full SDR records and thresholds
FRU inventory	512-byte FRU 0 image with Board and Product areas; Write FRU Data kept in on-chip flash across a reset; write protection input; serial numbers, part numbers, asset tag and manufacturing date writable per unit
FRU state and payload	FRU states M0 to M7; payload power enable, power good, fault and reset signals; startup self test
Firmware update	bootloader in its own flash sectors; image length and SHA-256 check before every start; Intel HEX load over the console or the application port, with a host update tool
Payload CPU link	application port (UART) for status, local IPMI requests and the per-unit FRU fields
Diagnostics	console command line; IPMB capture log of every frame, exported as CSV or as a trace for Wireshark
Configuration	one Rust file holds every tunable: identity strings, sensor names and thresholds, bus enables, master method, IPMB rules; compile-time checks reject invalid values

Tiers

Tier	Commands	What the Tier adds
Tier-1	14	Device ID, self test, Device SDR, sensor readings, FRU inventory read and write, VSO capabilities, Set IPMB State, Device Locator Record ID, FRU address information
Tier-2	18	event receiver, Platform Event messages to the Chassis Manager, Cold Reset, FRU Control Capabilities
Tier-3	36	Warm Reset, FRU Control, FRU activation and policy bits, payload modes, sensor event enables, the System Event Log and its time, FRU hash, Mandatory Sensor Numbers, BMC global enables, 400 kHz IPMB

Verification

Evidence	Result
Host and tool tests (Rust and Python)	1,320 test cases, 1,253 tests run, 1,253 passed, each with its recorded result
Conformance suite	written from the VITA 46.11 and IPMI texts only, by an author who does not read the implementation; runs against the board or the emulator. Tier-3 build: 101 requirement cases, 78 tests run, 78 passed; Tier-2 build: 65 requirement cases, 54 tests run, 54 passed
Captured system traffic	the emulator replays the IPMB traffic of a live VPX chassis and compares every answer
Third-party Chassis Manager	an independent VITA 46.11 Chassis Manager's Linux code, compiled for a PC and driving a real IPMB, discovers the IPMC, walks its SDR, reads its FRU inventory and sensors: 198 requests, 198 answers, no checksum errors

Offerings

Offering	Contents
Tier-1 source	the full Tier-1 source, free to download, build and evaluate; a commercial license for deployment in a product
Tier-2 and Tier-3 licenses	source of the Tier-2/3 extension, per project or part number, with 12 months of updates and support; units are royalty-free
Evaluation image	a Tier-3 firmware image for the NUCLEO-F401RE board (buy the board, part 497-14360-ND) that serves the IPMB for a fixed time after each start
Engineering services	port to your microcontroller and board, your sensors, FRU and SDR content, bring-up against your Chassis Manager

Hardware needed

The IPMC needs two I2C ports for IPMB-A and IPMB-B, GPIO for the geographic address straps and the payload power signals, an ADC for the rails, and one UART for the console. Commands that VITA 46.11 requires only for a payload system interface, subsidiary FRU EEPROMs or a power supply module are outside the standard build.