

Acme Split AC 1.5T

Service Manual

1. Product Overview

The Acme Split AC 1.5T is a 1.5-ton inverter split air conditioner (R-32 refrigerant) with an indoor evaporator unit and outdoor condenser. This manual covers airflow, cooling performance, and electrical faults. Switch off at the isolator before servicing.

2. Components

- Indoor unit — evaporator coil, blower wheel, washable air filters, and PCB.
- Outdoor unit — compressor, condenser coil, and fan.
- Remote / display board with error-code LEDs.
- Temperature thermistors (room and coil).
- Drain pan and drain hose.
- Inverter PCB and capacitor bank.

3. Common Issues, Causes & Fixes

3.1 Unit runs but cooling is weak.

Possible causes:

- Dirty / clogged air filters restricting airflow.
- Iced or dirty evaporator coil.
- Low refrigerant charge (R-32).

Fix: Remove and wash the air filters. If the coil is iced, run fan-only to defrost and check airflow. If suction line is not cold and superheat is high, have a technician check refrigerant charge.

3.2 Indoor unit leaks water inside the room.

Possible causes:

- Blocked drain hose.
- Drain pan misaligned or cracked.

Fix: Flush the drain hose with water to clear algae blockage. Re-level the indoor unit so it slopes slightly toward the drain.

3.3 Outdoor unit does not start, error LED blinking.

Possible causes:

- Faulty start/run capacitor.
- Coil thermistor fault reported on the PCB.

Fix: Read the blink code against the table inside the indoor cover. Test the capacitor for rated microfarads. Measure thermistor resistance against the temperature chart; replace if open or shorted.

4. Maintenance Schedule

Task	Interval	Notes
Clean air filter	Every 3 months	Wash and dry before refitting.
Condenser coil cleaning	Every 6 months	Clear leaves and dust from outdoor coil.
Drain line flush	Every 6 months	Prevents indoor water leakage.
Refrigerant + electrical inspection	Every 12 months	Technician check of charge and capacitor.