

Connecting with PC

While connecting the ST-LINK/V2 (mini) to the computer through USB interface, the USB driver is required and should be installed correctly first.

Click on the link to download : [ST-LINK/V2 USB driver for Windows 7, Vista and XP](#)

Connection with STM8/STM32 applications

The ST-LINK/V2 (mini) should be connected to the STM8 application via the SWIM interface.

DEBUGGER PIN	TARGET BOARD PIN	DESCRIPTION
VCC	MCU VCC	STM8 VCC
SWIM	MCU SWIM	STM8 SWIM PIN
GND	GND	STM8 GND
RST	MCU RESET	STM8 RESET PIN

The ST-LINK/V2 (mini) should be connected to the STM32 application via the SWD interface.

DEBUGGER PIN	TARGET BOARD PIN	DESCRIPTION
VCC	MCU VCC	STM32 VCC
SWDIO	MCU SWDIO	STM32 SWD SWDIO
GND	GND	STM32 GND
SWCLK	MCU SWCLK	STM32 SWD SWCLK

Please note that the VCC and GND should be connected correctly to avoid any harm to the ST-LINK/V2 (mini).

Wiki: [www.waveshare.com/wiki/ST-LINK/V2_\(mini\)](http://www.waveshare.com/wiki/ST-LINK/V2_(mini))



Contact