ISA/IEC 62443-3-3 / 4-2 • SL-3 TESTING CHEAT SHEET

Rockwell Automation PowerFlex 6000T Medium-Voltage AC Drive (TotalFORCE) · Component type: **Embedded Device (EDR) - medium-voltage VFD, CIP Security-capable** · Target SL = SL 3

Where to work	The **10-in. color touchscreen operator terminal** on the drive; **CCW / Studio 5000** drive AOP via **FactoryTalk Linx 6.11+**; **FactoryTalk Policy Manager + System Services** (CA) for CIP Security; **ControlFLASH Plus** + PCDC for signed firmware; **FactoryTalk AssetCentre** for audit/DR. EtherNet/IP is via the **ENETR** option (PROFIBUS via 13TCOMMP1).
MV context	Medium-voltage drive (2.3-11 kV). Physical security and safety are first-class: HV cabinet with **door interlocks**, isolation/grounding, and key/permit systems. TotalFORCE control means the security-relevant parameters mirror the 755T (drive host = Port 0; 0:230 Write Mask, 0:324 Logic Mask).
Notes	EDR - MV AC drive, PowerFlex 6000T (TotalFORCE). Confirm firmware rev, the comm option (ENETR), and whether CIP Security/Protection Mode are actually enabled (capability present does not mean configured). Confirm operator-terminal authentication is enabled.
How to read	Read-only: review the touchscreen config/roles, the CCW/Studio 5000 parameter set, and the FactoryTalk Policy Manager CIP Security model. Native how-to (exact location/param) + external-tool validation + pass. Scans authorized; fuzz ISOLATED lab only. MV: observe all HV safety/permit rules on site.

FR 1 — Identification & Authentication Control (IAC)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 1.1	Human user identification & auth	Verify layered access: (1) **Operator terminal login** - confirm the 10-in. touchscreen requires a login with access levels (not an always-unlocked screen). (2) **CIP Security Protection Mode** enabled so only certificate-authenticated tools/controllers can connect/write (confirm in FactoryTalk Policy Manager). (3) **Write protection** 0:230 [Write Mask Cfg]. (4) FactoryTalk Security for the AOP. **Test:** at the terminal confirm restricted screens require login; connect a non-enrolled tool - Protection Mode must refuse it. **Ext. tools:** Terminal (login/roles); FactoryTalk Policy Manager (Protection Mode); non-enrolled connect (isolated) - refused.	Terminal login + Protection Mode + Write Mask enforce authenticated access.	
SR/CR 1.2	Software process / device identification	Confirm unique identity and, under CIP Security, mutual certificate authentication. Read the ENETR/embedded identity (IP/host name) in CCW/Studio 5000; confirm the drive certificate identity in Policy Manager. **Ext. tools:** FactoryTalk Policy Manager (cert identity); CCW (IP/name); Wireshark.	Unique, certificate-bound device identity; partners authenticated.	
SR/CR 1.3	Account management	Review the terminal operator/engineer roles and the FactoryTalk users/roles for the AOP - remove defaults, least privilege; manage CIP Security enrollment membership in Policy Manager. **Ext. tools:** Terminal role review; FactoryTalk Admin Console; Policy Manager membership.	Terminal + FactoryTalk accounts managed, least-privilege; defaults changed.	
SR/CR 1.4	Identifier management	Confirm unique terminal/FactoryTalk user IDs and a unique drive identity (EtherNet/IP address + host name + certificate + serial); no reuse. **Ext. tools:** Terminal/FactoryTalk; Policy Manager; CCW device info.	Unique user, device, and certificate identifiers; no reuse.	
SR/CR 1.5 / 1.7	Authenticator management & strength	Enforce strong terminal and FactoryTalk passwords; change all defaults. CIP Security adds certificate keys - confirm key strength/rotation in Policy Manager. **Ext. tools:** Terminal/FactoryTalk password policy; Policy Manager key/cert policy.	Strong managed authenticators + certificate keys; no defaults.	
SR/CR 1.6	Wireless Access Management	**N/A.** No wireless interface on this device; wireless access is managed at the network layer.	N/A - justification recorded (not assessed as a control).	N/A
SR/CR 1.8	PKI certificates	Confirm the 6000T holds a device certificate issued by the asset-owner CA (**FactoryTalk System Services**), valid/not-default, with a managed trust list in Policy Manager. **Ext. tools:** FactoryTalk Policy Manager (certificate status); openssl.	CA-issued device certificate; defaults replaced; trust list managed.	

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 1.9	Strength of public key auth	Confirm CIP Security uses TLS/DTLS with current cipher suites and strong keys; no weak/expired certs. **Ext. tools:** Wireshark (DTLS/TLS suite); Policy Manager review.	Strong crypto on secured channels.	
SR/CR 1.10	Authenticator feedback	Confirm the terminal login, CCW/Studio 5000 logon, and FactoryTalk logon obscure the secret during entry. **Ext. tools:** Visual verification at each interface.	Authenticators obscured during entry.	
SR/CR 1.11	Unsuccessful login attempts	Confirm the terminal and FactoryTalk lock/throttle repeated failed logins and record them; monitor via AssetCentre/SIEM. **Ext. tools:** Terminal/FactoryTalk lockout policy; SIEM failed-auth.	Failed logins locked/throttled/logged.	
SR/CR 1.12	System use notification	The 10-in. terminal **can** present the approved use-notification banner at login - confirm it is configured; also enforce the notice on the EWS (GPO). **Ext. tools:** Terminal banner config; EWS GPO review.	Use notice shown at the terminal and EWS.	
SR/CR 1.13	Access via untrusted networks	Confirm the ENETR EtherNet/IP is reachable only from the trusted cell zone behind the cell firewall / Stratix ACLs; remote engineering via VPN; with Protection Mode on, in-zone tools must still authenticate. **Ext. tools:** Nmap (from untrusted side); firewall/ACL review.	Untrusted-network access denied; in-zone access still authenticated.	

FR 2 — Use Control (UC)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 2.1	Authorization enforcement	Verify least-privilege command/config: terminal roles gate operate vs configure; 0:324 [Logic Mask] restricts which ports may Start/Jog/Direction (Stop never masked); 0:230 [Write Mask] restricts write ports; Protection Mode blocks unauthenticated writes. **Test:** as a low-privilege terminal user or unauthenticated tool, attempt a config change/Start - must be refused. **Ext. tools:** Terminal role test; CCW (0:324/0:230); Policy Manager; unauthorized attempt (isolated).	Terminal roles + Logic/Write Mask + Protection Mode enforce least privilege.	
SR/CR 2.2	Wireless Use Control	**N/A.** No wireless interface on this device; wireless access is managed at the network layer.	N/A - justification recorded (not assessed as a control).	N/A
SR/CR 2.3	Use control for portable/mobile devices	Control the engineering laptop and USB/SD; removable-media policy on the EWS; only authorized projects loaded. **Ext. tools:** Physical inspection; EWS removable-media policy.	Portable/engineering media controlled.	
SR/CR 2.4 (+ EDR 2.4)	Mobile code	No general-purpose mobile code; confirm only signed firmware + configured parameters run and terminal/web content is vendor-supplied. **Ext. tools:** CCW / terminal review.	Only trusted firmware/config runs; no untrusted mobile code.	EDR-specific.
SR/CR 2.5	Session lock	Confirm the terminal auto-locks on inactivity (returns to login) and CCW/Studio 5000 sessions time out and require re-auth. **Ext. tools:** Terminal inactivity-lock config; CCW timeout.	Terminal and engineering sessions lock/timeout; re-auth required.	
SR/CR 2.6	Remote session termination	Confirm remote engineering / CIP sessions can be terminated and idle sessions close; enrollment limits who can reconnect. **Ext. tools:** FactoryTalk Linx / connection review; Wireshark.	Remote sessions terminable on demand and on inactivity.	
SR/CR 2.7	Concurrent session control	Confirm concurrent programming/monitoring connections are bounded and monitored; the CIP connection limit prevents conflicting simultaneous config. **Ext. tools:** CCW/adapter connection review; FactoryTalk Linx.	Concurrent privileged sessions limited/monitored.	
SR/CR 2.8 / 2.12	Auditable events & non-repudiation	Confirm configuration/firmware changes are captured in **FactoryTalk AssetCentre** (Audit + DR) with the acting user; the terminal event log and drive fault/alarm queue are read; forward events to the SIEM. TotalFORCE health data can corroborate. **Ext. tools:** AssetCentre audit; terminal event log / drive fault queue; Syslog/SIEM.	Config/firmware changes audited and attributable.	

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 2.9	Audit storage capacity	Terminal log and drive fault queue are finite; rely on AssetCentre/SIEM for retention; confirm sizing and threshold alerting. **Ext. tools:** AssetCentre DB sizing; SIEM retention.	Events offloaded and retained; alert before capacity.	
SR/CR 2.10	Response to audit processing failures	Confirm the SIEM/AssetCentre alerts on forwarding/collection failure. **Ext. tools:** SIEM / AssetCentre health alerting.	Audit-failure alerting defined.	
SR/CR 2.11	Timestamps	Confirm the terminal/controller time source is NTP-synced so terminal-log, AssetCentre, and SIEM timestamps are accurate and correlate. **Ext. tools:** NTP / terminal/controller time review.	Reliable, synchronized timestamps.	
EDR 2.13	Physical diagnostic & test interfaces	MV-specific: the drive lives in an HV cabinet with **door interlocks**, isolation, and grounding - confirm interlocks/permits are functional and the cabinet is locked. Control the terminal USB, ENETR/option ports, and any service laptop port; disable unused services. **Ext. tools:** Physical inspection (interlocks/locks/grounding); CCW/terminal (port/service config).	HV interlocks + cabinet locks intact; diagnostic interfaces controlled; unused services off.	EDR-specific.

FR 3 — System Integrity (SI)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 3.1 / 4.1	Communication integrity & confidentiality	Confirm **CIP Security** provides integrity + confidentiality (DTLS/TLS) on the ENETR EtherNet/IP with Protection Mode enforcing it; verify with a capture that channels are secured, not cleartext CIP. **Ext. tools:** Wireshark (secured vs cleartext CIP); Policy Manager.	Comms integrity + confidentiality via CIP Security; Protection Mode enforced.	
EDR 3.2	Protection from malicious code (component)	Confirm only Rockwell-signed firmware runs. 6000T/TotalFORCE firmware ships as signed .dmk; ControlFLASH Plus/the drive validates the signature and rejects unsigned/altered images. **Ext. tools:** ControlFLASH Plus (signature verify); PCDC checksum.	Only signed firmware runs; component protected.	EDR-specific.
SR/CR 3.3	Security functionality verification	After any change re-verify: Protection Mode/CIP Security state, 0:230 Write Mask, 0:324 Logic Mask, terminal login/roles, and services, against the baseline; CCW compare to the archived project. **Ext. tools:** CCW compare; Policy Manager; terminal role review; Nmap.	Security settings match the hardening baseline after change.	
SR/CR 3.4	Software & information integrity	Archive the parameter set / project in AssetCentre; enable change detection; keep Write Mask restrictive and Protection Mode on so unauthorized parameter/firmware change is prevented/detected. **Ext. tools:** AssetCentre change detection; CCW online-vs-offline compare.	Config integrity protected; unauthorized change prevented/detected.	
SR/CR 3.5	Input validation	Confirm the drive tolerates malformed EtherNet/IP/CIP frames without faulting or unsafe operation. **ISOLATED only:** fuzz on a bench/representative control section - never on an energized MV drive - and watch fault queue / connection status. **Ext. tools:** ENIP/CIP fuzzer (ISOLATED, de-energized); Wireshark.	No crash or unsafe operation on malformed input.	Do NOT fuzz an energized MV drive.
SR/CR 3.6	Deterministic output	Verify the fault / comm-loss reaction so the drive reaches a defined safe state: set the ENETR **Comm Flt Action** and **Idle Flt Action** and the drive **Fault Config** to a safe stop/coast as designed; verify the MV protection/trip and any safety-permit interlocks that remove output. **Ext. tools:** CCW (Comm/Idle Flt Action + Fault Config); MV trip/interlock function test (planned outage).	Drive trips/stops to a defined safe state on fault or comm loss.	
SR/CR 3.7	Error handling	Confirm graceful fault handling: fault/alarm queue, defined trip actions, auto-restart disabled unless justified; no unsafe restart of an MV drive. **Ext. tools:** CCW/terminal (fault queue + fault actions; auto-restart config).	Graceful fault handling; no unsafe restart or info leak.	
SR/CR 3.8	Session integrity	With CIP Security, sessions are integrity-protected against replay/hijack; confirm secured channels in use (Protection Mode) and no unauthenticated session path remains. **Ext. tools:** Wireshark (session inspection); Policy Manager.	Sessions integrity-protected; no unauthenticated path.	
SR/CR 3.9	Protection of audit information	Protect the AssetCentre audit DB and Syslog transport; restrict who can read/clear the terminal log and drive fault queue. **Ext. tools:** AssetCentre DB access review; SIEM access review.	Audit records protected from unauthorized read/modify/delete.	

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
EDR 3.10	Support for updates	Update firmware only with Rockwell-signed .dmk via **ControlFLASH Plus** (signature validated); plan in a maintenance/outage window with rollback to the prior signed revision; cross-check against PCDC. **Ext. tools:** ControlFLASH Plus (signed update/verify); PCDC checksum.	Signed firmware updates only, with a controlled update + rollback path.	EDR-specific.
EDR 3.11	Physical tamper resistance/detection	MV-specific: HV cabinet locked/sealed with door interlocks and grounding; control the terminal/USB/ENETR ports; AssetCentre audit + fault queue record config/firmware changes as tamper evidence. **Ext. tools:** Physical inspection (interlocks/locks/seals); AssetCentre / fault-queue review.	HV cabinet locked/sealed/interlocked; interfaces controlled; changes logged.	EDR-specific.
EDR 3.12	Provisioning product-supplier roots of trust	The drive accepts only Rockwell-signed firmware (supplier root of trust); confirm the signing chain is intact and unsigned/altered .dmk is rejected at load. **Ext. tools:** ControlFLASH Plus (verify); attempt unsigned image (isolated) -> rejected.	Supplier signing root intact; unsigned/altered firmware rejected.	EDR-specific.
EDR 3.13	Provisioning asset-owner roots of trust	Confirm the asset owner's **FactoryTalk System Services** is the CA and the 6000T is enrolled with its certificate managed in **FactoryTalk Policy Manager**. **Ext. tools:** FactoryTalk Policy Manager / System Services (CA + enrollment).	Asset-owner certificate provisioning verified.	EDR-specific.
EDR 3.14	Integrity of the boot process	Confirm the drive validates signed-firmware integrity before execution; no unsigned/tampered firmware runs. Capture the firmware revision + signed status (terminal diagnostics or CCW device info). **Ext. tools:** CCW/terminal (firmware revision/signed status); ControlFLASH Plus.	Firmware integrity validated before execution; only signed firmware boots.	EDR-specific.

FR 4 — Data Confidentiality (DC)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 4.2	Information persistence	On decommission/repurpose, reset the drive to defaults, clear terminal config/accounts and CIP Security enrollment/certificates, and sanitize/destroy any SD so configuration and keys are not recoverable. **Ext. tools:** CCW/terminal (reset/clear); Policy Manager (remove enrollment); media sanitize.	Config + certificates purged on decommission or reuse.	
SR/CR 4.3	Use of cryptography	Confirm CIP Security uses modern crypto (TLS/DTLS, strong suites); disable any legacy unauthenticated web/service; certificates/keys managed in FactoryTalk. **Ext. tools:** Wireshark / testssl.sh; Policy Manager review.	Modern crypto in use; legacy services disabled.	

FR 5 — Restricted Data Flow (RDF)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 5.1 / 5.2	Network segmentation & zone boundary	Confirm the drive sits in a controlled cell/zone behind a firewall / Stratix ACLs; only required EtherNet/IP flows cross the boundary; CIP Security + segmentation are defense-in-depth. **Ext. tools:** Nmap by zone; firewall/ACL rule review.	Drive in a segmented zone; only required flows cross the boundary.	
SR/CR 5.3	General-purpose person-to-person comms restrictions	**N/A.** Single-purpose embedded MV drive with no general-purpose person-to-person communications. **Ext. tools:** Confirm no such services on the drive/terminal.	N/A - justification recorded (single-purpose embedded device).	N/A
SR/CR 5.4	Application partitioning	**N/A.** Single-purpose drive; no separable applications to partition. **Ext. tools:** Confirm single-function device.	N/A - justification recorded.	N/A

FR 6 — Timely Response to Events (TRE)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 6.1 / 6.2	Audit log accessibility & continuous monitoring	Confirm terminal-log and drive faults/alarms and AssetCentre change records are readable/exportable and forwarded to the SIEM; the cell is passively monitored (OT IDS on a mirror port). TotalFORCE analytics feed condition monitoring. **Ext. tools:** AssetCentre export; terminal-log export; passive OT IDS.	Events accessible/exportable and monitored in near-real-time.	

FR 7 — Resource Availability (RA)

Req (3-3 / 4-2)	Requirement	Where & how to verify (native steps + Ext. tools)	Pass criteria / evidence	Notes / firmware
SR/CR 7.1	Denial-of-service protection	Confirm DoS resilience: drive CIP connection limits plus cell-firewall rate-limiting prevent a flood from denying control; CIP Security drops unauthenticated floods early. Monitor connection load while testing. **Ext. tools:** Adapter connection review; traffic generator (ISOLATED).	Resources bounded; drive control continues under load.	
SR/CR 7.2	Resource management	Confirm the drive/ENETR bounds resource use (max CIP connections, comms load) so a single service cannot starve control. **Ext. tools:** Adapter connection/limits review.	Resources bounded; no exhaustion-based loss of control.	
SR/CR 7.3 / 7.4	Backup & recovery	Confirm the parameter set / project and terminal config are backed up (AssetCentre DR, versioned, offline) and a restore is tested for a known-good rebuild (including CIP Security re-enrollment). **Ext. tools:** AssetCentre DR review; restore test (planned).	Backups current and recovery validated.	
SR/CR 7.5	Emergency Power	**N/A.** Emergency/backup power is provided at the facility/UPS level, not the device; confirm the device retains its security state across a power transfer.	N/A - justification recorded (not assessed as a control).	N/A
SR/CR 7.6 / 7.7	Network & security settings + least functionality	Confirm hardening: Protection Mode on, disable unused terminal/web/services, disable unused option-module functions/ports, set 0:230 Write Mask / 0:324 Logic Mask restrictively, terminal login enabled. **Ext. tools:** CCW (masks/services); Policy Manager (Protection Mode); terminal config; Nmap.	Least functionality; unused services disabled per baseline.	
SR/CR 7.8	Component inventory	Confirm the drive (catalog, firmware rev, option modules, ENETR, terminal) is inventoried so vulnerabilities track against Rockwell Automation security advisories. **Ext. tools:** CCW/AssetCentre inventory; ReadOnlyEnum.	Accurate component/firmware inventory maintained.	

External Test Tools — how to use

Tool / method	Verifies	How to use — steps / example	Constraints
10-in. Operator Terminal	On-drive login, roles, banner, logs (1.1, 1.11, 1.12, 2.5, 6.x)	Confirm terminal login/roles, inactivity lock, use-notification banner, and event log at the drive.	Physical; authorized; observe HV rules.
CCW / DriveExecutive / Studio 5000	Native config & protection review (all FRs)	Read parameters (0:230 Write Mask, 0:324 Logic Mask, fault/comm-loss actions, firmware rev); compare to baseline.	Read/authorized project copy.
FactoryTalk Policy Manager / System Services	CIP Security model, CA & Protection Mode (1.1, 1.8, 3.1, 3.13)	Confirm the 6000T is enrolled, certificate valid, Protection Mode on, trust list managed.	Read-only.
FactoryTalk AssetCentre	Audit, change detection & DR (2.8, 3.4, 6.x, 7.3)	Audit config/firmware changes; versioned backup/restore.	Non-intrusive.
ControlFLASH Plus / PCDC	Signed firmware update & verify (3.2, 3.10, 3.12, 3.14)	Verify the drive accepts only Rockwell-signed .dmk; cross-check PCDC checksums.	Outage window.

Tool / method	Verifies	How to use — steps / example	Constraints
Nmap / Wireshark	Exposed-service, zone & secured-comms review (1.13, 3.1, 5.x, 7.6)	Enumerate EtherNet/IP per zone; confirm CIP Security channels and Protection Mode behavior.	Read-only/passive; authorized.
ENIP/CIP fuzzer / traffic generator	Input validation & DoS resilience (3.5, 7.1)	Malformed-frame / high-rate testing on a bench/de-energized control section while watching fault queue / connection health.	ISOLATED; de-energized; written authorization.

Controlled - Project Use · Independent Assurance Authority · ISA/IEC 62443-3-3 / 4-2 · Product-specific companion to the 62443 assessment tool; confirm exact menu paths / CLI against the deployed firmware and the project hardening baseline. ISOLATED tools run only in a representative/lab environment with written authorization.