ISO Geodetic Registry

Item class Conversion

Name UTM zone 2N

Item status VALID
Identifier 888

Alias UTM zone 2

Information source Title Geomatics Guidance Note No 7, part 2:

Coordinate Conversions and Transformations

including Formulas

Author International Association of Oil and Gas

Producers (IOGP)

Publisher International Association of Oil and Gas

Producers (IOGP)

Revision date 2021-11 Edition 61

Series/Journal name IOGP Publication

Issue identification 373-7-2

Other citation details https://epsg.org/guidance-notes.html (accessed

2022-01-19)

Information source Title The Universal Grids and the Transverse Mercator

and Polar Stereographic Map Projections

Author National Geospatial-Intelligence Agency (NGA)
Publisher National Geospatial-Intelligence Agency (NGA)

Revision date 2014-03-25

Series/Journal name National Geospatial-Intelligence Agency

Standardization Document

Issue identification NGA.SIG.0012_2.0.0_UTMUPS Version 2.0.0

Other citation details https://nsgreg.nga.mil/doc/view?

i=4056&month=3&day=28&year=2022 (accessed

0.0

2022-04-20)

Data source ISO Geodetic Registry

Remarks NGA zone names using postitive zone numbers for northern

hemisphere and negative zone numbers for southern hemisphere are

specified as alias name.

South-bound latitude

Scope Spatial referencing

Operation method Transverse Mercator Projection

Extent

World - onshore and offshore - between 174°W and 168°W, northern hemisphere between equator and 84°N.

Geographic Bounding Box

West-bound longitude
North-bound latitude
East-bound longitude
-168.0

Operation parameter values

Latitude of natural origin0.0 degreeLongitude of natural origin-171.0 degreeScale factor at natural origin0.9996 unityFalse easting500000.0 metre

Retrieved: 1970-01-01T00:00:00+00:00 // Last Registry change: 2023-10-02T11:41Z

Fal	se	nort	hing

0.0 metre

ISO Geodetic Registry

Item class OperationMethod

Name Transverse Mercator Projection

Item status VALID
Identifier 834

Alias Gauss-Boaga

*Alia*s TM

Alias Gauss-Kruger

Data source ISO Geodetic Registry

Operation parameters

Latitude of natural origin

Longitude of natural origin

Scale factor at natural origin

False easting

False northing